



MODEL NUMBER DESIGNATION - OUTBOARDS

Model Years 1980-1998




Model Years 1999-2001



MODEL NUMBER DESIGNATION - OUTBOARDS

Model Years 2002 and Up



RECREATIONAL OUTBOARDS 1980-1999

1.2 HP Models

Model Number	Year
JCO-CDR	1986
EJR-CDR	1986
JCO-CUA	1987
EJR-CUA	1987
JCO-CCM	1988
EJR-CCM	1988
JCO-CE	1989
EJR-CE	1989
JCO-ES	1990
EJR-ES	1990

2 HP Models

Model Number	Year
2RCS	1980
2RCI	1981
2RCN	1982
2RCT	1983
2RCR	1984
2RCO	1985
2REC / 2RLEC	1998
2REE	1999

2.3 HP Models

Model Number	Year
H2REI	1991
H2REN	1992
H2RET / H2DRET	1993
H2RER / H2DRER	1994
H2REO / H2ROEO	1995
H2RED / H2ROED	1996
2REU / 2ROEU	1997

2.5 HP Models

Model Number	Year
3RCU	1987
3RCC	1988

3 HP Models

Model Number	Year
3BRES	1990
3REI	1991
3REN	1992
3RET	1993
3RER	1994
3REO	1995
3RED	1996
3REU	1997

3.3 HP Models

Model Number	Year
H3REI	1991
H3REN	1992
H3RET	1993
H3RER	1994
H3ROEO	1995
3ROED	1996
3ROEU	1997
3ROEC / 3ROLE	1998
3REE / 3RLEE	1999
3ROEE	1999

4 HP Models

Model Number	Year
4BRCS / 4BRLCS	1980
4RLCS	1980
4WCS	1980
4BRCI / 4BRLCI	1981
4BRHCI / 4BRHLCI	1981
4WCI	1981
4BRCN / 4BRLCN	1982
4BRHCN / 4BRHLCN	1982
4WCN	1982
4BRCT / 4BRLCT	1983
4BRHCT / 4BRHLCT	1983
4BRCR / 4BRLCR	1984
4BRHCR / 4BRHLCR	1984
4RDCR / 4RDLCR	1984
4RDHCR / 4RDHLCR	1984
4BRCO / 4BRLCO	1985
4BRHCO / 4BRHCLO	1985
4RDCO / 4RDLCO	1985
4RDHCO / 4RDHLCO	1985
4BRCD / 4BRLCD	1986
4BRHCD / 4BRHLCD	1986
4RDGD / 4RDGLD	1986
4RDHGD / 4RDHGLD	1986
4BRCU / 4BRLCU	1987
4BRHCU / 4BRHLCU	1987
4RCU / 4RLCU	1987
4RDHCU / 4RDHLCU	1987
4BRCC / 4BRLCC	1988
4BRHCC / 4BRHLCC	1988
4RCC / 4RLCC	1988
4RDHCC / 4RDHLCC	1988
4BRHCE / 4BRHLCE	1989
4RCE / 4RLCE	1989
4RDHCE / 4RDHLCE	1989

4BRES / 4BRLES	1990
4BRHES / 4BRHLES	1990
4RDHES / 4RDHLES	1990
4RES / 4RLES	1990
4BREI / 4BRLEI	1991
4RDHEI / 4RDHLEI	1991
4REI / 4RLEI	1991
4BREN / 4BRLEN	1992
4RDHEN / 4RDHLEN	1992
4REN / 4RLEN	1992
4BRET / 4BRLET	1993
4RDHET / 4RDHLET	1993
4RET / 4RLET	1993
4BRER / 4BRLER	1994
4RDHER / 4RDHLER	1994
4RER / 4RLER	1994
4BREO / 4BRLEO	1995
4RDHEO / 4RDHLEO	1995
4REO / 4RLEO	1995
4BRED / 4BRLED	1996
4RDHED / 4RDHLED	1996
4RED / 4RLED	1996
4BREU / 4BRLEU	1997
4REU / 4RLEU	1997
4BREC / 4BRLEC	1998
4REE / 4RLEE	1999

4.5 HP Models

Model Number	Year
5BACS / 5BALCS	1980
5RCS / 5RLCS	1980
5RHCS / 5RHLC	1980
5RCI / 5RLCI	1981
5RHCI / 5RHLCI	1981
5RCN / 5RLCN	1982
5RHCN / 5RHLCN	1982
5RCT / 5RLCT	1983
5RHCT / 5RHLC	1983
5RHCR	1984
5RHCO	1985
5RHCD	1986
5RHCU	1987

RECREATIONAL OUTBOARDS 1980-1999

5 HP Models

Model Number	Year
5BFCR / 5BFPCR	1984
5BFCO / 5BFPCO	1985
5BFCD / 5BFPCD	1986
5BFCU / 5BFPCU	1987
5DRCC / 5DRPC	1988
5DRCE / 5DRPC	1989
5DRES / 5DRLES	1990
5DREI / 5DRLEI	1991
5DREN / 5DRLEN	1992
5DRET / 5DRLET	1993
5DRER / 5DRLER	1994
5DREO / 5DRLEO	1995
5DRED / 5DRLED	1996
5FRED / 5FRLED	1996
5DREU / 5DRLEU	1997
5FRBEU / 5FRBLEU	1997
5FREU / 5FRLEU	1997
5DREC / 5DRLEC	1998
5FRBEC / 5FRBLEC	1998
5FREC / 5FRLEC	1998
5REC / 5RLEC	1998
5R4EE / 5RL4EE	1999
5RB4EE / 5RBL4EE	1999
5REE / 5RLEE	1999

6 HP Models

Model Number	Year
6BFCS / 6BFPCS	1980
6BFCL / 6BFPL	1981
6RCI	1981
6BFCLN / 6BFPLN	1982
6RCN / 6RCLN	1982
6BACT / 6BALCT	1983
6BFCLT / 6BFPLT	1983
6RCLT	1983
6BACL / 6BALCL	1984
6BFCLR / 6BFPLR	1984
6RCR / 6RCLR	1984
6SLCR	1984
6BACL / 6BALCL	1985
6BFCL / 6BFPL	1985
6RCL / 6RCL	1985
6SLCL	1985
6BACL / 6BALCL	1986
6BFCL / 6BFPL	1986
6RCL / 6RCL	1986
6SLCL	1986

6BACU / 6BALCU	1987
6BFCLU / 6BFPLU	1987
6SLCU	1987
6BACC / 6BALCC	1988
6DRCC / 6DRPC	1988
6RCC / 6RCL	1988
6SLC	1988
6BACE / 6BALCE	1989
6DRCE / 6DRPC	1989
6RCE / 6RCL	1989
6SLCE	1989
6BAES / 6BALES	1990
6DRES / 6DRLES	1990
6RES / 6RLES	1990
6SLE	1990
6BAEI / 6BALEI	1991
6DREI / 6DRLEI	1991
6REI / 6RLEI	1991
6SLEI	1991
6DREN / 6DRLEN	1992
6REN / 6RLEN	1992
6SLEN	1992
6DRET / 6DRLET	1993
6RET / 6RLET	1993
6SLET	1993
6DRER / 6DRLER	1994
6RER / 6RLER	1994
6SLER	1994
6DREO / 6DRLEO	1995
6REO / 6RLEO	1995
6SLEO	1995
6DRED / 6DRLED	1996
6FRBED / 6FRBLED	1996
6FRED / 6FRLED	1996
6RED / 6RLED	1996
6SLED	1996
6DREU / 6DRLEU	1997
6FRBEU / 6FRBLEU	1997
6FREU / 6FRLEU	1997
6REU / 6RLEU	1997
6DREC / 6DRLEC	1998
6FREC / 6FRLEC	1998
6REC / 6RLEC	1998
6R4EE / 6RL4EE	1999
6REE / 6RLEE	1999

7.5 HP Models

Model Number	Year
8BACS / 8BALCS	1980
8RCS / 8RLCS	1980
8BACI / 8BALCI	1981
8RCI / 8RCL	1981
8BACN / 8BALCN	1982
8RCN / 8RCLN	1982
8SRLCN	1982
8BACT / 8BALCT	1983
8RCLT / 8RLCT	1983
8SRLCT	1983

8 HP Models

Model Number	Year
8BACL / 8BALCL	1984
8RCR / 8RCLR	1984
8SRLCR	1984
8BACL / 8BALCL	1985
8RCL / 8RCL	1985
8SRLCL	1985
8BACL / 8BALCL	1986
8RCL / 8RCL	1986
8SRLCL	1986
8BACU / 8BALCU	1987
8RCLU / 8RCLU	1987
8SRLCU	1987
8BACC / 8BALCC	1988
8RCC / 8RCC	1988
8SRLCC	1988
8BACE / 8BALCE	1989
8RCE / 8RCL	1989
8SRLCE	1989
8BAES / 8BALES	1990
8RES / 8RLES	1990
8SRLES	1990
8BAEI / 8BALEI	1991
8REI / 8RLEI	1991
8SRLEI	1991
8REN / 8RLEN	1992
8RET / 8RLET	1993
8SRLET	1993
8RER / 8RER	1994
8SRLER	1994
8REO / 8RLEO	1995
8SRLEO	1995
8FRBED / 8FRBLED	1996
8FRBXED	1996
8FRED / 8FRLED	1996
8FRXED	1996
8RED / 8RLED	1996

RECREATIONAL OUTBOARDS 1980-1999

<i>15 HP Models</i>				<i>20 HP Models</i>	
Model Number	Year			Model Number	Year
15BACS / 15BALCS	1980	15RER / 15RLER	1994	20BFCS / 20BFLCS	1980
15ECS / 15ELCS	1980	15RGER / 15RGLER	1994	20CRCS / 20CRLCS	1980
15RCS / 15RLCS	1980	15BAEO	1995	20BFCI / 20BFLCI	1981
15BACI / 15BALCI	1981	15DBLEO	1995	20CRCI / 20CRLCI	1981
15ECI	1981	15DLEO	1995	20BFCN / 20BFLCN	1982
15RCI / 15RLCI	1981	15EEO / 15ELEO	1995	20BICN / 20BILCN	1982
15BACN / 15BALCN	1982	15FBEO / 15FBLEO	1995	20CRCN / 20CRLCN	1982
15ECN	1982	15FREO / 15FRLEO	1995	20BFCT / 20BFLCT	1983
15RCN / 15RLCN	1982	15KBEO	1995	20BICT / 20BILCT	1983
15BACT / 15BALCT	1983	15KEO	1995	20CRCT / 20CRLCT	1983
15ECT / 15ELCT	1983	15RELEO	1995	20BFCT / 20BFLCT	1983
15RCT / 15RLCT	1983	15REO / 15RLEO	1995	20BICR / 20BILCR	1984
15BACR / 15BALCR	1984	15RGEO / 15RGLEO	1995	20CRCR / 20CRLCR	1984
15ECR / 15ELCR	1984	15BAED	1996	20BFCT / 20BFLCT	1984
15RCR / 15RLCR	1984	15EED / 15ELED	1996	20BICO / 20BILCO	1985
15BACO / 15BALCO	1985	15FAED	1996	20CRCO / 20CRLCO	1985
15ECO / 15ELCO	1985	15FDLED	1996	20ECO / 20ELCO	1985
15RCO / 15RLCO	1985	15FKED	1996	20BFCD / 20BFLCD	1986
15BACD / 15BALCD	1986	15FRED / 15FRLED	1996	20BICD / 20BILCD	1986
15ECD / 15ELCD	1986	15FRELED	1996	20CRCD / 20CRLCD	1986
15RCD / 15RLCD	1986	15FWED / 15FWLED	1996	20ECD / 20ELCD	1986
15BACU / 15BALCU	1987	15RED / 15RLED	1996	20TECD	1986
15ECU / 15ELCU	1987	15RELED	1996	20BFCD / 20BFLCD	1986
15RCU / 15RLCU	1987	15BAEU	1997	20BICD / 20BILCD	1986
15BACC / 15BALCC	1988	15EEU / 15ELEU	1997	20CRCD / 20CRLCD	1986
15ECC / 15ELCC	1988	15FAEU	1997	20ECD / 20ELCD	1986
15RCC / 15RLCC	1988	15FDLEU	1997	20TECD	1986
15BACE / 15BALCE	1989	15FKEU	1997	20BFCD / 20BFLCD	1986
15ECE / 15ELCE	1989	15FRELEU	1997	20BICU / 20BILCU	1987
15RCE / 15RLCE	1989	15FREU / 15FRLEU	1997	20CRCU / 20CRLCU	1987
15SPCE / 15SPLCE	1989	15FWEU / 15FWLEU	1997	20ECU / 20ELCU	1987
15BAES / 15BALES	1990	15RELEU	1997	20TECU	1987
15EES / 15ELES	1990	15REU / 15RLEU	1997	20BFCC / 20BFLCC	1988
15RELES	1990	15BAEC	1998	20CRCC / 20CRLCC	1988
15RES / 15RLES	1990	15EEC / 15ELEC	1998	20ECC / 20ELCC	1988
15SPES / 15SPLES	1990	15FDLEC	1998	20TECC / 20TELCC	1988
15BAEI / 15BALEI	1991	15FREC / 15FRLEC	1998	20BFCE / 20BFLCE	1989
15EEI / 15ELEI	1991	15FRELEC	1998	20CRCE / 20CRLCE	1989
15REI / 15RLEI	1991	15FWEC / 15FWLEC	1998	20ECE / 20ELCE	1989
15RELEI	1991	15REC / 15RLEC	1998	20TECE / 20TELCE	1989
15BAEN / 15BALEN	1992	15RELEC	1998	20BFES / 20BFLES	1990
15EEN / 15ELEN	1992	15BAEE	1999	20CRES / 20CRLES	1990
15RELEN	1992	15EBL4EE	1999	20EES / 20ELES	1990
15REN / 15RLEN	1992	15EL4EE	1999	20TEES / 20TELES	1990
15EET / 15ELET	1993	15EEE	1999	20BFEI / 20BFLEI	1991
15RELET	1993	15R4EE / 15RL4EE	1999	20CREI / 20CRLEI	1991
15RET / 15RLET	1993	15RB4EE / 15RBL4EE	1999	20EEI / 20ELEI	1991
15EER / 15ELER	1994	15REE / 15REE	1999	20TEEI / 20TELEI	1991
15RELER	1994	15RTEE	1999	20BFEN / 20BFLEN	1992
		15TEEE / 15TELEE	1999	20CREN / 20CRLEN	1992
				20EEN / 20ELEN	1992
				20SEEN / 20SELEN	1992
				20SREN / 20SRLEN	1992
				20BFET / 20BFLET	1993
				20CRET / 20CRLET	1993

RECREATIONAL OUTBOARDS 1980-1999

20EET / 20ELET	1993	25BACO / 25BALCO	1985	25DEEI / 25DELEI	1991
20SEET / 20SELET	1993	25BECO / 25BELCO	1985	25DREI / 25DRLEI	1991
20SRET / 20SRLET	1993	25BFCO / 25BFLCO	1985	25DTLEI	1991
20CRER / 20CRLER	1994	25ECO / 25ELCO	1985	25EEI / 25ELEI	1991
20EER / 20ELER	1994	25RCO / 25RLCO	1985	25IEEI / 25IELEI	1991
20SEER / 20SELER	1994	25TECO / 25TELCO	1985	25IREI / 25IRLEI	1991
20SRER / 20SRLER	1994	25BACD / 25BALCD	1986	25RAEI / 25RALEI	1991
20CREO / 20CRLEO	1995	25BECD / 25BELCD	1986	25REI / 25RLEI	1991
20EEO / 20ELEO	1995	25BFCD / 25BFLCD	1986	25SEEI / 25SELEI	1991
20SEEO / 20SELEO	1995	25ECD / 25ELCD	1986	25SREI / 25SRLEI	1991
20SREO / 20SRLEO	1995	25RACD / 25RALCD	1986	25TEEI / 25TELEI	1991
20CRED / 20CRLED	1996	25RCD / 25RLCD	1986	25DEEN / 25DELEN	1992
20SEED / 20SELED	1996	25TECD / 25TELCD	1986	25DREN / 25DRLEN	1992
20SRED / 20SRLED	1996	25BACU / 25BALCU	1987	25DTLEN	1992
20CREU / 20CRLEU	1997	25ECU / 25ELCU	1987	25EEN / 25ELEN	1992
20SEEU / 20SELEU	1997	25IECU / 25IELCU	1987	25IEEN / 25IELEN	1992
20SREU / 20SRLEU	1997	25IRCU / 25IRLCU	1987	25IREN / 25IRLEN	1992
20SEEC / 20SELEC	1998	25RACU / 25RALCU	1987	25RAEN / 25RALEN	1992
20SREC / 20SRLEC	1998	25RCU / 25RLCU	1987	25REN / 25RLEN	1992
		25TECU / 25TELCU	1987	25SEEN / 25SELEN	1992
		25BACC / 25BALCC	1988	25SREN / 25SRLEN	1992
		25ECC / 25ELCC	1988	25TEEN / 25TELEN	1992
		25IECC / 25IELCC	1988	25DEET / 25DELET	1993
		25IRCC / 25IRLCC	1988	25DRET / 25DRLET	1993
		25RACC / 25RALCC	1988	25DTLET	1993
		25RCC / 25RLCC	1988	25EET / 25ELET	1993
		25SECC / 25SELCC	1988	25RAET / 25RALET	1993
		25SRCC / 25SRLCC	1988	25RET / 25RLET	1993
		25TECC / 25TELCC	1988	25SEET / 25SELET	1993
		25DECE / 25DELCE	1989	25SRET / 25SRLET	1993
		25DRCE / 25DRLCE	1989	25TEET / 25TELET	1993
		25DTLCE	1989	25BAER / 25BALER	1994
		25ECE / 25ELCE	1989	25DEER / 25DELER	1994
		25IECE / 25IELCE	1989	25DRER / 25DRLER	1994
		25IRCE / 25IRLCE	1989	25DTLER	1994
		25RACE / 25RALCE	1989	25EER / 25ELER	1994
		25RCE / 25RLCE	1989	25RAER / 25RALER	1994
		25SECE / 25SELCE	1989	25RER / 25RLER	1994
		25SRCE / 25SRLCE	1989	25SEER / 25SELER	1994
		25TECE / 25TELCE	1989	25SIKLER	1994
		25DEES / 25DELES	1990	25SILER	1994
		25DRES / 25DRLES	1990	25SITER	1994
		25DTLES	1990	25SRER / 25SRLER	1994
		25EES / 25ELES	1990	25TEER / 25TELER	1994
		25IEES / 25IELES	1990	25BAEO / 25BALEO	1995
		25IRES / 25IRLES	1990	25BREO / 25BRLEO	1995
		25RAES / 25RALES	1990	25DEEO / 25DELEO	1995
		25RES / 25RLES	1990	25DREO / 25DRLEO	1995
		25SEES / 25SELES	1990	25DTLEO	1995
		25SRES / 25SRLES	1990	25EEO / 25ELEO	1995
		25TEES / 25TELES	1990	25EREO / 25ERLEO	1995

25 HP Models	
Model Number	Year
25BACS / 25BALCS	1980
25BECS / 25BELCS	1980
25BFCS / 25BFLCS	1980
25ECS / 25ELCS	1980
25RCS / 25RLCS	1980
25TECS / 25TELCS	1980
25BACI / 25BALCI	1981
25BECI / 25BELCI	1981
25BFCI / 25BFLCI	1981
25ECI / 25ELCI	1981
25RCI / 25RLCI	1981
25TECI / 25TELCI	1981
25BACN / 25BALCN	1982
25BECN / 25BELCN	1982
25BF CN / 25BFLCN	1982
25ECN / 25ELCN	1982
25RCN / 25RLCN	1982
25TECN / 25TELCN	1982
25BACT / 25BALCT	1983
25BECT / 25BELCT	1983
25BFCT / 25BFLCT	1983
25ECT / 25ELCT	1983
25RCT / 25RLCT	1983
25BACR / 25BALCR	1984
25BE CR / 25BELCR	1984
25BF CR / 25BFLCR	1984
25ECR / 25ELCR	1984
25RCR / 25RLCR	1984
25TECR / 25TELCR	1984

RECREATIONAL OUTBOARDS 1980-1999

25FAEO / 25FALEO	1995
25JREO	1995
25KEO / 25KLEO	1995
25QLEO	1995
25RAEO / 25RALEO	1995
25RDEO	1995
25REO / 25RLEO	1995
25RMEO / 25RMLEO	1995
25SEEO / 25SELEO	1995
25SIKLEO	1995
25SILEO	1995
25SITLEO	1995
25SREO / 25SRLEO	1995
25TEEO / 25TELEO	1995
25TKLEO	1995
25ARED / 25ARLED	1996
25BAED / 25BALED	1996
25BRED / 25BRLED	1996
25EED / 25ELED	1996
25ERED / 25ERLED	1996
25JRED	1996
25KED / 25KLED	1996
25QLED	1996
25RAED	1996
25RDED	1996
25RED / 25RLED	1996
25RMED / 25RMLED	1996
25TEED / 25TELED	1996
25TKED / 25TKLED	1996
25AREU / 25ARLEU	1997
25BAEU / 25BALEU	1997
25EEU / 25ELEU	1997
25JREU	1997
25KEU / 25KLEU	1997
25QLEU	1997
25RAEU	1997
25RDEU	1997
25REU / 25RLEU	1997
25RMEU / 25RMLEU	1997
25TEEU / 25TELEU	1997
25TKEU / 25TKLEU	1997
25AREC / 25ARLEC	1998
25BAEC / 25BALEC	1998
25EEC / 25ELEC	1998
25JREC	1998
25KEC / 25KLEC	1998
25QLEC	1998
25RDEC	1998
25REC / 25RLEC	1998
25RMEC / 25RMLEC	1998
25TEEC / 25TELEC	1998

25TKEC / 25TKLEC	1998
25EEE / 25ELEE	1999
25JREE	1999
25PL3EE	1999
25R3EE / 25RL3EE	1999
25RDEE	1999
25REE / 25RLEE	1999
25RTEE	1999
25TEEE / 25TELEE	1999
25TEL3EE	1999

28 HP Models

Model Number	Year
28ELCD	1986
28ESLCU	1987
28ESLCC	1988
28ESLCE	1989
28ESLES	1990
28ESLEI	1991
28ESLEN	1992
28ESLET	1993
28ESLER	1994
28ESLEO	1995
28ESLED	1996

30 HP Models

Model Number	Year
30ECR / 30ELCR	1984
30BACO / 30BALCO	1985
30ECO / 30ELCO	1985
30RCO / 30RLCO	1985
30TECO / 30TELCO	1985
30BACD / 30BALCD	1986
30ECD / 30ELCD	1986
30RCD / 30RLCD	1986
30TECD / 30TELCD	1986
30BACU / 30BALCU	1987
30ECU / 30ELCU	1987
30RCU / 30RLCU	1987
30TECU / 30TELCU	1987
30BACC / 30BALCC	1988
30ECC / 30ELCC	1988
30RCC / 30RLCC	1988
30TECC / 30TELCC	1988
30BACE / 30BALCE	1989
30ECE / 30ELCE	1989
30RCE / 30RLCE	1989
30TECE / 30TELCE	1989
30BAES / 30BALES	1990
30EES / 30ELES	1990
30RES / 30RLES	1990

30TEES / 30TELES	1990
30BAEI / 30BALEI	1991
30EEI / 30ELEI	1991
30REI / 30RLEI	1991
30TEEI / 30TELEI	1991
30BAEN / 30BALEN	1992
30EEN / 30ELEN	1992
30REN / 30RLEN	1992
30TEEN / 30TELEN	1992
30BAET / 30BALET	1993
30EET / 30ELET	1993
30RET / 30RLET	1993
30TEET / 30TELET	1993
30BAER / 30BALER	1994
30EER / 30ELER	1994
30RER / 30RLER	1994
30TEER / 30TELER	1994
30BAEO / 30BALEO	1995
30EEO / 30ELEO	1995
30REO / 30RLEO	1995
30TEEO / 30TELEO	1995
30BAED / 30BALED	1996
30EED / 30ELED	1996
30RED / 30RLED	1996
30TEED / 30TELED	1996
30BAEU / 30BALEU	1997
30EEU / 30ELEU	1997
30ESLEU	1997
30REU / 30RLEU	1997
30TEEU / 30TELEU	1997
30BAEC / 30BALEC	1998
30EEC / 30ELEC	1998
30RPEC / 30RPLEC	1998
30TEEC / 30TELEC	1998
30BAEE	1999
30EEE / 30ELEE	1999
30JREE	1999
30REE / 30RLEE	1999
30RPEE / 30RPLEE	1999

35 HP Models

Model Number	Year
35BACS / 35BALCS	1980
35ECS / 35ELCS	1980
35RCS / 35RLCS	1980
35BACI / 35BALCI	1981
35ECI / 35ELCI	1981
35RCI / 35RLCI	1981
35BACN / 35BALCN	1982
35ECN / 35ELCN	1982
35RCN / 35RLCN	1982

RECREATIONAL OUTBOARDS 1980-1999

35TELCN	1982	35KEE	1999	40TTLEI	1991
35BACT / 35BALCT	1983	35PL3EE	1999	40BAEN / 40BALEN	1992
35ECT / 35ELCT	1983	35R3EE / 35RL3EE	1999	40EEN / 40ELEN	1992
35RCT / 35RLCT	1983	35TEL3EE	1999	40REN / 40RLEN	1992
35TELCT	1983			40TEEN / 40TELEN	1992
35BACR / 35BALCR	1984			40TLEN	1992
35ECR / 35ELCR	1984			40TTLEN	1992
35RCR / 35RLCR	1984			40BAET / 40BALET	1993
35TELCR	1984			40EET / 40ELET	1993
35RCO / 35RLCO	1985			40RET / 40RLET	1993
35AECD / 35AELCD	1986			40TEET / 40TELET	1993
35ARCD / 35ARLCD	1986			40TLET	1993
35ATECD / 35ATELCD	1986			40TTLET	1993
35RCD / 35RLCD	1986			40BAER / 40BALER	1994
35AELCU	1987			40EER / 40ELER	1994
35ARCU / 35ARLCU	1987			40RER / 40RLER	1994
35ATECU / 35ATELCU	1987			40TEER / 40TELER	1994
35ATLCU	1987			40TLER	1994
35RCU / 35RLCU	1987			40TTLER	1994
35RCC / 35RLCC	1988			40BAEO / 40BALEO	1995
35RCE / 35RLCE	1989			40EEO / 40ELEO	1995
35RES / 35RLES	1990			40JREO	1995
35REI / 35RELEI	1991			40REEO / 40RLEO	1995
35REN / 35RLEN	1992			40TEEO / 40TELEO	1995
35RET / 35RLET	1993			40TLEO	1995
35RER / 35RLER	1994			40TTLEO	1995
35EEO / 35ELEO	1995			40EED / 40ELED	1996
35FAEO / 35FALEO	1995			40JRED	1996
35FLEO	1995			40RED / 40RLED	1996
35KLEO	1995			40TEED / 40TELED	1996
35QLEO	1995			40TLED	1996
35REO / 35RLEO	1995			40TTLED	1996
35ARED / 35ARLED	1996			40EEU / 40ELEU	1997
35KED / 35KLED	1996			40JREU	1997
35QLED	1996			40REU / 40RLEU	1997
35RED / 35RLED	1996			40TEEU / 40TELEU	1997
35RMLED	1996			40TLEU	1997
35TKLED	1996			40TTLEU	1997
35AREU / 35ARLEU	1997			40EEC / 40ELEC	1998
35KEU / 35KLEU	1997			40JPLEC	1998
35QLEU	1997			40JREC	1998
35RMLEU	1997			40REC / 40RLEC	1998
35TKLEU	1997			40TEEC / 40TELEC	1998
35AREC / 35ARLEC	1998			40TLEC	1998
35KEC / 35KLEC	1998			40TTLEC	1998
35QLEC	1998			40EEE / 40EELE	1999
35TKLEC	1998			40JPLEE	1999
35AREE	1999			40PLEE	1999
35E3EE / 35EL3EE	1999			40REE / 40RLEE	1999
				40TPLEE	1999

40 HP Models

Model Number	Year
40ECR / 40ELCR	1984
40RCR / 40RLCR	1984
40TECR / 40TELCR	1984
40BACO / 40BALCO	1985
40ECO / 40ELCO	1985
40RCO / 40RLCO	1985
40TECO / 40TELCO	1985
40BACD / 40BALCD	1986
40ECD / 40ELCD	1986
40RCD / 40RLCD	1986
40TECD / 40TELCD	1986
40TLCD	1986
40BACU / 40BALCU	1987
40ECU / 40ELCU	1987
40RCU / 40RLCU	1987
40TECU / 40TELCU	1987
40TLCU	1987
40AELCC	1988
40ARLCC	1988
40ATLCC	1988
40BACC / 40BALCC	1988
40ECC / 40ELCC	1988
40RCC / 40RLCC	1988
40TECC / 40TELCC	1988
40TLCC	1988
40TTLCC	1988
40BACE / 40BALCE	1989
40ECE / 40ELCE	1989
40RCE / 40RLCE	1989
40TECE / 40TELCE	1989
40TLCE	1989
40TTLCE	1989
40BAES / 40BALES	1990
40EES / 40ELES	1990
40RES / 40RLES	1990
40TEES / 40TELES	1990
40TLES	1990
40TTLES	1990
40BAEI / 40BALEI	1991
40EEI / 40ELEI	1991
40REI / 40RLEI	1991
40TEEI / 40TELEI	1991
40TLEI	1991

RECREATIONAL OUTBOARDS 1980-1999

48 HP Models

Model Number	Year
48CELCS	1980
48ESLCU	1987
48ESLCC	1988
48ESLCE	1989
48ESLES	1990
48ESLEI	1991
48ESLEN	1992
48ESLET	1993
48ESLER	1994
48ESLEO	1995
48ESLED	1996

50 HP Models

Model Number	Year
50BECS / 50BELCS	1980
50ECS / 50ELCS	1980
50BECI / 50BELCI	1981
50BECN / 50BELCN	1982
50BECT / 50BELCT	1983
50TELCT	1983
50BECR / 50BELCR	1984
50TELCR	1984
50TLCR	1984
50BECO / 50BELCO	1985
50TELCO	1985
50TLCO	1985
50BECD / 50BELCD	1986
50TELCD	1986
50TLCD	1986
50BECU / 50BELCU	1987
50TELCU	1987
50TLCU	1987
50BECC / 50BELCC	1988
50TELCC	1988
50TLCC	1988
50BECE / 50BELCE	1989
50TELCE	1989
50TLCE	1989
50BEES / 50BELES	1990
50TELES	1990
50TLES	1990
50BEEI / 50BELEI	1991
50JEI	1991
50TELEI	1991
50TLEI	1991
50BEEN / 50BELEN	1992
50JEN	1992
50TELEN	1992
50TLEN	1992

50BEET / 50BELET	1993
50JET	1993
50TLET / 50TELET	1993
50BEER / 50BELER	1994
50JER	1994
50TELER	1994
50TLER	1994
50BEEO / 50BELEO	1995
50DTLEO	1995
50ELEO	1995
50JEO	1995
50KLEO	1995
50TELEO	1995
50TLEO	1995
50TTLEO	1995
50BEED / 50BELED	1996
50DTLED	1996
50ELED	1996
50JED	1996
50RLED	1996
50TLED	1996
50TTLED	1996
50DTLEU	1997
50ELEU	1997
50ESEU / 50ESLEU	1997
50JEU	1997
50RLEU	1997
50TLEU	1997
50TTLEU	1997
50DTLEC	1998
50ESEC / 50ESLEC	1998
50RLEC	1998
50TLEC	1998
50TSLEC	1998
50TTLEC	1998
50EEE / 50EEEL	1999
50PLEE	1999
50RLEE	1999

55 HP Models

Model Number	Year
55E80 / 55EL80	1980
55RLCS	1980
55074 / 55075	1980
55RCN / 55RLCN	1982
55RCT / 55RLCT	1983
55RPLEC	1998
55RPLEE	1999

60 HP Models

Model Number	Year
60ECS / 60ELCS	1980
60TLCS	1980
60ECI / 60ELCI	1981
60TLCI	1981
60ECN / 60ELCN	1982
60TLCN	1982
60ECT / 60ELCT	1983
60TLCT	1983
60ECR / 60ELCR	1984
60TLCR	1984
60ECO / 60ELCO	1985
60TLCO	1985
60ELCD	1986
60TLCD	1986
60ELCU	1987
60TLCU	1987
60ELCC	1988
60TLCC	1988
60TTLCC	1988
60ELCE	1989
60TLCE	1989
60TTLCE	1989
60ELES	1990
60TLES	1990
60TTLES	1990
60ELEI	1991
60TLEI	1991
60TTLEI	1991
60ELEN	1992
60TLEN	1992
60TTLEN	1992
60ELET	1993
60TLET	1993
60TTLET	1993
60ELER	1994
60TLER	1994
60TTLER	1994
60ELEO	1995
60TLEO	1995
60TTLEO	1995
60ELED	1996
60TLED	1996
60TTLED	1996
60ELEU	1997
60TLEU	1997
60TTLEU	1997
60TLEC	1998
60TTLEC	1998

RECREATIONAL OUTBOARDS 1980-1999

<i>70 HP Models</i>		<i>75 HP Models</i>		<i>90 HP Models</i>	
Model Number	Year	Model Number	Year	Model Number	Year
70ELCS	1980	75BERCS	1980	90MLCI	1981
70TLCS	1980	75ERCS / 75ERLCS	1980	90TLCI / 90TXCI	1981
70ELCI	1981	75TRLCS	1980	90MLCN	1982
70TLCI	1981	75ERCI / 75ERLCI	1981	90TLCN / 90TXCN	1982
70ELCN	1982	75TRLCI	1981	90MLCT	1983
70TLCN	1982	75ERCN / 75ERLCN	1982	90TLCT / 90TXCT	1983
70ELCT	1983	75TRLCN	1982	90MLCR	1984
70TLCT	1983	75ECT	1983	90TLCR / 90TXCR	1984
70ELCR	1984	75ELCT	1983	90MLCO	1985
70TLCR	1984	75ERCT / 75ERLCT	1983	90TLCO / 90TXCO	1985
70ELCO	1985	75TLCT	1983	90MLCD	1986
70TLCO	1985	75TRLCT	1983	90TLCD / 90TXCD	1986
70ELCD	1986	75ECR	1984	90MLCU	1987
70TLCD	1986	75ELCR	1984	90TLCU	1987
70ELCU	1987	75TLCR	1984	90MLCC	1988
70TLCU	1987	75ECO	1985	90TLCC / 90TXCC	1988
70ELCC	1988	75ELCO	1985	90MLCE	1989
70TLCC	1988	75TLCO	1985	90TLAE	1989
70ELCE	1989	75ECD	1986	90TLCE / 90TXCE	1989
70TLCE	1989	75ECU	1987	90MLES	1990
70ELES	1990	75ECC	1988	90TLAS	1990
70TLES / 70TXES	1990			90TLES / 90TXES	1990
70ELEI	1991			90JLEI	1991
70TLEI / 70TXEI	1991			90MLEI	1991
70TTLEI	1991			90SLEI	1991
70ELEN	1992			90TLAI	1991
70TLEN / 70TXEN	1992			90TLEI / 90TXEI	1991
70TTLEN	1992			90JLEN	1992
70ELET	1993			90MLEN	1992
70TLET / 70TXET	1993			90SLEN	1992
70TTLET	1993			90TLAN	1992
70ELER	1994			90TLEN / 90TXEN	1992
70TLER / 70TXER	1994			90JLET	1993
70TTLER	1994			90MLET	1993
70ELEO	1995			90SLET	1993
70JLEO	1995			90TLAT	1993
70TLEO / 70TXEO	1995			90TLET / 90TXAT	1993
70TTLEO	1995			90JLER	1994
70ELED	1996			90MLER	1994
70TLED / 70TXED	1996			90TLAR	1994
70ELEU / 70TLEU	1997			90TLER / 90TXAR	1994
70TXEU	1997			90ELEO / 90EXEO	1995
70ELEC	1998			90JLEO	1995
70EPLEC	1998			90MLEO	1995
70FTLEC	1998			90SLEO	1995
70JLEC	1998			90TLEO / 90TXAO	1995
70TLEC	1998			90ELED / 90EXED	1996
70EPLEE	1999			90MLED	1996
70PL4EE	1999			90SLED / 90SXED	1996
70PLEE	1999				

<i>85 HP Models</i>	
Model Number	Year
85MLCS	1980
85TLCS / 85TXCS	1980
85TTLEI	1991
85TTLEN	1992
85TTLET	1993
85TTLER	1994
85TTLEO	1995

<i>88 HP Models</i>	
Model Number	Year
88MSLCU	1987
88MSLCC	1988
88MSLCE	1989
88MSLES	1990
88MSLEI	1991
88MSLEN	1992
88MSLET	1993
88MSLER	1994
88TSLER	1994
88MSLEO	1995
88TSLEO	1995
88MSLED	1996
88TSLED	1996

RECREATIONAL OUTBOARDS 1980-1999

90TLED / 90TXAD	1996
90ELEU / 90EXEU	1997
90SLEU / 90SXEU	1997
90TSLEU	1997
90ELEC	1998
90FSLEC	1998
90FTLEC	1998
90SLEC / 90SXE	1998
90TSLEC	1998
L90GLEC	1998
90FPLEE	1999
90PLEE / 90PXEE	1999

100 HP Models

Model Number	Year
100MLCS	1980
100TLCS	1980
100TXCS	1980
100STLCC	1988
100STLCE	1989
100SLES	1990
100STLES	1990
100SLEI	1991
100STLEI	1991
100SLEN	1992
100STLEN	1992
100SLET	1993
100STLET	1993
100STLER	1994

110 HP Models

Model Number	Year
110MLCD	1986
110TLCD	1986
110MLCU	1987
110TLCU / 110TXCU	1987
110MLCC	1988
110TLCC / 110TXCC	1988
110MLAE	1989
110MLCE	1989
110TLAE	1989
110TLCE / 110TXCE	1989

112 HP Models

Model Number	Year
112SLER / 112SXER	1994
112TSLER / 112TSXER	1994
112TSLEO / 112TSXEO	1995
112SLED / 112SXED	1996
112TSLED / 112TSXED	1996

115 HP Models

Model Number	Year
115MLCS	1980
115TLCS / 115TXCS	1980
115MLCI	1981
115TLCI / 115TXCI	1981
115MLCN	1982
115TLCN / 115TXCN	1982
115MLCT	1983
115TLCT / 115TXCT	1983
115MLCR	1984
115TLCR / 115TXCR	1984
115MLCO	1985
115TLCO	1985
115MLES	1990
115TLAS	1990
115TLES / 115TXES	1990
115JLEI	1991
115MLEI	1991
115SLEI	1991
115TLAI	1991
115TLEI / 115TXEI	1991
115JLEN	1992
115MLEN	1992
115SLEN	1992
115TLAN	1992
115TLEN / 115TXEN	1992
115JLET	1993
115MLET	1993
115TLAT / 115TXAT	1993
115TLET / 115TXET	1993
V115SHLET	1993
V115SLET	1993
115JKLER	1994
115JLER	1994
115MLER	1994
115TLAR	1994
115TLER / 115TXAR	1994
115ELEO	1995
115GLEO	1995
115JKLEO	1995
115JLEO	1995
115MLEO	1995
115SLEO / 115SXEO	1995
115TLEO	1995
115TXAO	1995
L115GLEO	1995
115ELED	1996
115GLED	1996
115JLED	1996
115SLED / 115SXED	1996

115TLED / 115TXAD	1996
L115GLED	1996
115ELEU	1997
115GLEU	1997
115HLEU	1997
115HXEU	1997
115JLEU	1997
115SLEU / 115SXEU	1997
115TSLEU / 115TSXEU	1997
L115GLEU	1997
115ELEC	1998
115FSLEC / 115FSXEC	1998
115FTLEC	1998
115GLEC	1998
115HLEC / 115HXEC	1998
115JTLEC	1998
115SLEC / 115SXEC	1998
115TSLEC / 115TSXEC	1998
L115GLEC	1998
115FPLEE / 115FPXEE	1999
115FSLEE	1999
115JPLEE	1999
115PLEE / 115PXEE	1999

120 HP Models

Model Number	Year
120TLCO / 120TXCO	1985
120TLCD / 120TXCD	1986
120TLCU / 120TXCU	1987
120TLCC / 120TXCC	1988
120TLAE	1989
120TLCE / 120TXCE	1989
120TLAS	1990
120TLES / 120TXES	1990
120TLAI	1991
120TLEI / 120TXEI	1991
120TLAN	1992
120TLEN / 120TXEN	1992
120TLAT / 120TXAT	1993
120TLET / 120TXET	1993
120TLAR	1994
120TLER / 120TXAR	1994
120TXER	1994

RECREATIONAL OUTBOARDS 1980-1999

<i>130 HP Models</i>	
Model Number	Year
130TLER / 130TXER	1994
130CXAO	1995
130TLEO / 130TXAO	1995
130CXAD	1996
130TLED / 130TXAD	1996
130CXAU	1997
130TLEU / 130TXAU	1997
130TLEC / 130TXAC	1998
130PLEE / 130PXEE	1999

<i>140 HP Models</i>	
Model Number	Year
140MLCS	1980
140TRLCS / 140TRXCS	1980
140MLCI	1981
140TRLCI / 140TRXCI	1981
140MLCN	1982
140TRLCN / 140TRXCN	1982
140MLCT	1983
140TLCT / 140TXCT	1983
140TRLCT / 140TRXCT	1983
140MLCR	1984
140TLCR / 140TXCR	1984
140TLCO / 140TXCO	1985
140TLCD / 140TXCD	1986
140TLCU / 140TXCU	1987
140CXCC	1988
140TLCC / 140TXCC	1988
140CXCE	1989
140TLAE	1989
140TLCE / 140TXCE	1989
140CXES	1990
140TLAS	1990
140TLES / 140TXES	1990
140CXEI	1991
140TLAI	1991
140TLEI / 140TXEI	1991
140CXEN	1992
140TLAN	1992
140TLEN / 140TXEN	1992
140CXAT	1993
140CXET	1993
140TLAT / 140TXAT	1993
140TLET / 140TXET	1993
140CXARC	1994
140CXARK	1994
140CXERE	1994
140CXERK	1994
140TLARK	1994

140TLARR	1994
140TLERK	1994
140TLERR	1994
140TXARC	1994
140TXARK	1994
140TXERK	1994
140TXERR	1994

<i>150 HP Models</i>	
Model Number	Year
150TLCS / 150TXCS	1980
150TRLCS / 150TRXCS	1980
150TLCI / 150TXCI	1981
150TRLCI / 150TRXCI	1981
150TRLCN / 150TRXCN	1982
150STLCT	1983
150TLCT / 150TXCT	1983
150TRLCT / 150TRXCT	1983
150ANCRS	1984
150STLCR	1984
150TLCR / 150TXCR	1984
150ANCO	1985
150STLCO	1985
150TLCO / 150TXCO	1985
150STLCD	1986
150TLCD / 150TXCD	1986
150GTLCU	1987
150STLCU	1987
150TLCU / 150TXCU	1987
150CXCC	1988
150STLCC	1988
150TLCC / 150TXCC	1988
150CXCE	1989
150SLCE	1989
150STLCE	1989
150TLAE	1989
150TLCE / 150TXCE	1989
150CXES	1990
150SLES	1990
150STLES	1990
150TLAS	1990
150TLES / 150TXES	1990
150CXEI	1991
150ELAI	1991
150ELEI / 150EXEI	1991
150GLEI	1991
150JLEI	1991
150NXEI	1991
150SLEI	1991
150STLEI	1991
150TLAI	1991

150TLEI / 150TXEI	1991
150ELAN	1992
150ELEN / 150EXEN	1992
150GLEN	1992
150JLEN	1992
150NXEN	1992
150ELAT / 150EXAT	1993
150ELET / 150EXET	1993
150GLET	1993
150JLET	1993
150NXAT	1993
150NXET	1993
V150SLET / V150SHLET	1993
150ELAR / 150EXAR	1994
150ELER / 150GLER	1994
150EXER / 150CXER	1994
150JLER	1994
150NXER / 150NXAR	1994
150SLER / 150SHLER	1994
150SLERA	1994
150ELEO	1995
150EXEO / 150CXEO	1995
150GLEO	1995
150HLEO	1995
150JLEO	1995
150NXEO	1995
150SLEO	1995
150WCLO	1995
150CXED	1996
150ELED	1996
150EXED	1996
150GLED	1996
150ILED	1996
150JLED	1996
150NXED	1996
150SLED / 150EXED	1996
150WCLD	1996
L150GLED	1996
150ELEU	1997
150EXEU / 150CXEU	1997
150GLEU	1997
150ICXEU	1997
150ILEU	1997
150IXEU	1997
150JLEU	1997
150NXEU	1997
150PLEU	1997
150SLEU	1997
L150GLEU	1997
150ELEC	1998
150FCXEC	1998

RECREATIONAL OUTBOARDS 1980-1999

150FSLEC / 150FSXEC	1998	175SLER	1994	200STLCC	1988
150GLEC	1998	175EXEO / 175CXEO	1995	200TXCC / 200CXCC	1988
150ILEC	1998	175GLEO	1995	200CXCE	1989
150JLEC	1998	175NXEO	1995	200STLCE	1989
150NSEC	1998	175SLEO	1995	200TXCE	1989
150SLEC / 150EXEC	1998	175CXED	1996	200CXES	1990
L150GLEC	1998	175EXED	1996	200SLES	1990
150CXEE	1999	175GLED	1996	200STLES	1990
150FCXEE	1999	175NXED	1996	200TXES	1990
150FPLEE / 150FPXEE	1999	175SLED	1996	200CXEI	1991
150FSLEE	1999	175CXEU	1997	200SLEI / 200STLEI	1991
150JPLEE	1999	175EXEU	1997	200TXEI	1991
150PLEE / 150PXEE	1999	175GLEU	1997	200CXEN	1992
		175NXEU	1997	200SLEN / 200STLEN	1992
		175SLEU	1997	200TXEN	1992
		175FCXEC	1998	200CXAT / 200CZAT	1993
		175FSLEC / 175FSXEC	1998	200CXET / 200CZET	1993
		175FTLEC	1998	200SLET	1993
		175GLEC	1998	200STLET	1993
		175NSEC	1998	200TXAT / 200TZAT	1993
		175SLEC / 175EXEC	1998	200TXET / 200TZET	1993
		175CXEE	1999	200CXER / 200CZER	1994
		175FCXEE	1999	200CZAR / 200CXAR	1994
		175FPLEE / 175FPXEE	1999	200STLER	1994
		175PLEE / 175PXEE	1999	200TXAR / 200TZAR	1994
				200TXER / 200TZER	1994
				LE200SLER	1994
				LJ200SLER	1994
				200CXEO / 200CZEO	1995
				200STLEO / 200SLEO	1995
				200TXEO / 200TZEO	1995
				200CXED	1996
				200STLED / 200SLED	1996
				200TXED	1996
				LE200SLED	1996
				LJ200SLED	1996
				200CXEU	1997
				200SLEU	1997
				200STLEU	1997
				200TXEU	1997
				200CXEC	1998
				200STLEC / 200SLEC	1998
				200TLEC / 200TXEC	1998
				200CXEE	1999
				200FCXEE	1999
				200FPLEE / 200FPXEE	1999
				200FSLEE	1999
				200PLEE / 200PXEE	1999

<i>175 HP Models</i>	
Model Number	Year
175TLCS / 175TXCS	1980
175TRLCS / 175TRXCS	1980
175TLCI / 175TXCI	1981
175TRLCI / 175TRXCI	1981
175TRLCN / 175TRXCN	1982
175TLCT / 175TXCT	1983
175TRLCT / 175TRXCT	1983
175TLCO / 175TXCO	1985
175TLCD / 175TXCD	1986
175TLCU / 175TXCU	1987
175STLAC	1988
175STLCC	1988
175TLCC / 175TXCC	1988
175STLCE	1989
175TLCE / 175TXCE	1989
175STLES	1990
175TLES / 175TXES	1990
175EXEI	1991
175GLEI	1991
175SLEI	1991
175STLEI	1991
175TLEI / 175TXEI	1991
175EXEN	1992
175GLEN	1992
175NXEN	1992
175EXAT	1993
175EXET	1993
175GLET	1993
175NXAT	1993
175NXET	1993
175EXAR	1994
175EXER / 175CXER	1994
175GLER	1994
175NXAR	1994
175NXER	1994

<i>185 HP Models</i>	
Model Number	Year
185TLCR / 185TXCR	1984
185TLCO / 185TXCO	1985
185ESXW	1989
185ESXES	1990
185ESXEN	1992
185ESXET	1993
185ESXER	1994

<i>200 HP Models</i>	
Model Number	Year
200TLCS / 200TXCS	1980
200TRLCS / 200TRXCS	1980
200TLCI / 200TXCI	1981
200TRLCI / 200TRXCI	1981
200TLCN / 200TXCN	1982
200TRLCN / 200TRXCN	1982
200TLCT / 200TXCT	1983
200TRLCT / 200TRXCT	1983
200STLCD	1986
200TXCD	1986
200STLCU	1987
200TXCU	1987
200STLAC	1988

RECREATIONAL OUTBOARDS 1980-1999

<i>225 HP Models</i>	
Model Number	Year
225PTLCD / 225PTXCD	1986
225TLCD / 225TXCD	1986
225CLCU / 225CXCU	1987
225PLCU / 225PXCU	1987
225TLCU / 225TXCU	1987
225CXCC	1988
225PLCC / 225PXCC	1988
225TLCC / 225TXCC	1988
225CXCE	1989
225PLAE	1989
225PLCE / 225PXCE	1989
225TLAE	1989
225TLCE / 225TXCE	1989
225CXES	1990
225PLAS	1990
225PLES / 225PXES	1990
225TLAS	1990
225TLES / 225TXES	1990
225CXEI	1991
225PLEI / 225PXEI	1991
225TLEI / 225TXEI	1991
225CXEN	1992
225PLEN / 225PXEN	1992
225TLEN / 225STXEN	1992
225CXAT / 225CZAT	1993
225CXET / 225CZET	1993
225PLET / 225PXAT	1993
225PXET / 225PZET	1993
225PZAT	1993
225STLET	1993
225TLET	1993
225TXAT / 225TZAT	1993
225TXET / 225TZET	1993
225CXAR / 225CZAR	1994
225CXER / 225CZER	1994
225PXAR / 225PZAR	1994
225PXER / 225PZER	1994
225TLER / 225PLER	1994
225TXAR / 225TZAR	1994
225TXER / 225TZER	1994
225CXEO / 225CZEO	1995
225PXEO / 225PZEO	1995
225SLEO	1995
225STLEO	1995
225TXEO / 225TZEO	1995
225CXED / 225CZED	1996
225PXED	1996
225TXED / 225TZED	1996
225CXEU / 225CZEU	1997

225PXEU	1997
225SLEU	1997
225STLEU	1997
225TXEU / 225TZEU	1997
225CXEC / 225CZEC	1998
225NXEC / 225NZEC	1998
225QXEC / 225QZEC	1998
225STLEC / 225SLEC	1998
225TXEC / 225TZEC	1998
225CXEE	1999
225FCXEE / 225FCZEE	1999
225FPLEE / 225FPXEE	1999
225FPZEE	1999
225HPLLEE	1999
225PLEE / 225PXEE	1999

<i>235 HP Models</i>	
Model Number	Year
235TLGS / 235TXGS	1980
235TRLCS / 235TRXCS	1980
235TLCI / 235TXCI	1981
235TRLCI / 235TRXCI	1981
235TLCN / 235TXCN	1982
235TRLCN / 235TRXCN	1982
235STLCT	1983
235TLCT / 235TXCT	1983
235STLCR	1984
235TLCR / 235TXCR	1984
235STLCO	1985
235TLCO / 235TXCO	1985

<i>250 HP Models</i>	
Model Number	Year
250CXEI	1991
250TXEI	1991
250CXEN / 250CZEN	1992
250TXEN / 250TZEN	1992
250CXAT / 250CZAT	1993
250CXET / 250CZET	1993
250TXAT / 250TZAT	1993
250TXET / 200TZET	1993
250CXAR / 250CZAR	1994
250CXER / 250CZER	1994
250TXAR / 250TZAR	1994
250TXER / 250TZER	1994
250CXEO / 250CZEO	1995
250TXEO / 250TZEO	1995
250TXED / 250CXED	1996
250TXEU / 250CXEU	1997
250CXEC / 250CZEC	1998
250PXEC / 250PZEC	1998

250TXEC	1998
250CXEE / 250CZEE	1999
250PXEE / 250PZEE	1999

<i>275 HP Models</i>	
Model Number	Year
275TLCO / 275TXCO	1985
275PTLCD / 275PTXCD	1986
275CLCU / 275CXCU	1987
275PLCU / 275PXCU	1987
275CXCC	1988
275PLCC / 275PXCC	1988

<i>300 HP Models</i>	
Model Number	Year
300TLCO / 300TXCO	1985
300PTLCD / 300PTXCD	1986
300CLCU / 300CXCU	1987
300PLCU / 300PXCU	1987
300CXCC	1988
300PLCC / 300PXCC	1988
300CXCE	1989
300PLCE / 300PXCE	1989
300CXES	1990
300PLES / 300PXES	1990
300CXEI	1991
300PLEI / 300PXEI	1991
300CXEN	1992
300PLEN / 300PXEN	1992
300CXET	1993
300PLET / 300PXET	1993
300CXER	1994
300PLER / 300PXER	1994
300CXEO	1995
300PLEO / 300PXEO	1995

RECREATIONAL OUTBOARDS 2000-2005

2 HP Models

Model Number	Year
J2RTSSR	2000
J2RTSIA	2001
J2RTVSIA	2001

3 HP Models

Model Number	Year
J3RTSSR	2000
J3RTLSSR	2000

3.3 HP Models

Model Number	Year
J3RTLSIA	2001
J3RVLSIA	2001

3.5 HP Models

Model Number	Year
J3ROSIA	2001
J3RTSIA	2001
J3RTVSIA	2001
J3RSNF	2002
J3RSTB	2003
J3RSTF	2003
J3RSRE	2004
J3RSOD	2005

4 HP Models

Model Number	Year
J4RSSM	2000
J4RLSSM	2000
J4RSIB	2001
J4RLSIB	2001
J4RVSIB	2001
J4RVLSIB	2001
J4R4STS	2003
J4RL4STS	2003
J4R4SRC	2004
J4RL4SRC	2004
J4R4SOR	2005
J4RL4SOR	2005

5 HP Models

Model Number	Year
E5R4SSB	2000
E5RL4SSB	2000
E5RB4SSA	2000
E5RBL4SSA	2000
J5RSSA	2000
J5RLSSA	2000
E5R4SIE	2001
E5RL4SIE	2001
J5RSIM	2001
J5RLSIM	2001
J5RVSIM	2001
J5RVLSIM	2001
J5R4STS	2003
J5RL4STS	2003
J5R4SRC	2004
J5RL4SRC	2004
J5R4SOR	2005
J5RL4SOR	2005

6 HP Models

Model Number	Year
E6R4SSB	2000
E6RL4SSB	2000
J6RSSM	2000
J6RLSSM	2000
E6R4SIE	2001
E6RL4SIE	2001
J6RSIB	2001
J6RLSIB	2001
J6RVSIB	2001
J6RVLSIB	2001
J6R4STS	2003
J6RL4STS	2003
J6RSTD	2003
J6RLSTD	2003
J6R4SRC	2004
J6RL4SRC	2004
J6RSRS	2004
J6RLSRS	2004
J6R4SOS	2005
J6RL4SOS	2005
J6RSOC	2005
J6RLSOC	2005

8 HP Models

Model Number	Year
E8R4SSB	2000
E8RL4SSB	2000
E8RB4SSB	2000
E8RBL4SSB	2000
J8RSSB	2000
J8RLSSB	2000
J8RXSSB	2000
E8R4SIE	2001
E8RL4SIE	2001
E8RVL4SIC	2001
J8RSIE	2001
J8RLSIE	2001
J8RVSIE	2001
J8RVLSIE	2001
J8RXSIE	2001
J8RVXSIE	2001
J8RSTD	2003
J8RLSTD	2003
J8R4STS	2003
J8RL4STS	2003
J8R4SRC	2004
J8RL4SRC	2004
J8RSRC	2004
J8RLSRC	2004
J8RSOR	2005
J8RLSOR	2005

RECREATIONAL OUTBOARDS 2000-2005

9.9 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E8RVL4SSS	2000	E10R4SID	2001	J10RL4STC	2003
E10EBL4SSE	2000	E10RL4SID	2001	J10RSTE	2003
E10EL4SSE	2000	E10RK4SIS	2001	J10RLSTE	2003
E10EVL4SSS	2000	E10RLK4SIS	2001	J10TBL4STC	2003
E10R4SSE	2000	E10RV4SIC	2001	J10TE4STC	2003
E10RL4SSE	2000	E10RVL4SIC	2001	J10TEL4STC	2003
E10RV4SSS	2000	E10TEX4SID	2001	BJ10RH SRC	2004
E10RVL4SSS	2000	E10TVX4SIC	2001	BJ10RHLSRC	2004
E10TEX4SSE	2000	J10ELSIM	2001	J10EL4SRC	2004
E10TVX4SSS	2000	J10EVL S IC	2001	J10R4SRR	2004
J10ELSSA	2000	J10RGTSIC	2001	J10RL4SRR	2004
J10EVLSSS	2000	J10RLGTSIC	2001	J10RSRD	2004
J10RGTSSS	2000	J10RSIM	2001	J10RLSRD	2004
J10RLGTSSS	2000	J10RLSIM	2001	J10TBL4SRM	2004
J10RSSA	2000	J10RVSIC	2001	J10TE4SRR	2004
J10RLSSA	2000	J10RVLSIC	2001	J10TEL4SRR	2004
J10RVSSS	2000	J10TEGTSIC	2001	BJ10RHSOR	2005
J10RVLSSS	2000	J10TESIM	2001	BJ10RHLSOR	2005
J10TESSA	2000	J10TELSIM	2001	J10EL4SOR	2005
J10TELSSA	2000	J10TVESIM	2001	J10R4SOA	2005
J10TEGTSSS	2000	J10TVLSIM	2001	J10RL4SOA	2005
E10EBL4SID	2001	J10R4SNF	2002	J10RSOS	2005
E10EL4SID	2001	J10RL4SNF	2002	J10RLSOS	2005
E10ELK4SIS	2001	J10TE4SNF	2002	J10TBL4SOB	2005
E10EVK4SIS	2001	J10TEL4SNF	2002	J10TE4SOA	2005
E10EVL4SIC	2001	BJ10RHSTS	2003	J10TEL4SOA	2005
E10KV4SIS	2001	BJ10RHLSTS	2003		
E10KVL4SIS	2001	J10R4STC	2003		

RECREATIONAL OUTBOARDS 2000-2005

15 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E15EBL4SSE	2000	E15R4SID	2001	J15R4STC	2003
E15EL4SSE	2000	E15RL4SID	2001	J15RL4STC	2003
E15EVL4SSS	2000	E15RB4SID	2001	J15RSTD	2003
E15R4SSE	2000	E15RBL4SID	2001	J15RLSTD	2003
E15RL4SSE	2000	E15RV4SIC	2001	J15TE4STC	2003
E15RB4SSE	2000	E15RVL4SIC	2001	J15TEL4STC	2003
E15RBL4SSE	2000	J15ELSIB	2001	J15R4SRR	2004
E15RV4SSS	2000	J15EVL5IC	2001	J15RL4SRR	2004
E15RVL4SSS	2000	J15RSIB	2001	J15RSRS	2004
J15ELSSM	2000	J15RLSIB	2001	J15RLSRS	2004
J15EVLSSS	2000	J15RV5IC	2001	J15TE4SRR	2004
J15RSSM	2000	J15RVL5IC	2001	J15TEL4SRR	2004
J15RLSSM	2000	J15TESIB	2001	J15EL4SOS	2005
J15TESSM	2000	J15TELSIB	2001	J15R4SOA	2005
J15RTELSSM	2000	J15TVESIB	2001	J15RL4SOA	2005
J15RVSSS	2000	J15TVLSIB	2001	J15RSOC	2005
J15RVLSSS	2000	SJ15RVTSIR	2001	J15RLSOC	2005
SJ15RTSSB	2000	J15R4SNF	2002	J15TE4SOA	2005
E15EBL4SID	2001	J15RL4SNF	2002	J15TEL4SOA	2005
E15EL4SID	2001	J15TE4SNF	2002		
E15EVL4SIC	2001	J15TEL4SNF	2002		

RECREATIONAL OUTBOARDS 2000-2005

25 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E25EL4SSS	2000	BJ25ELSIC	2001	J25RLSNF	2002
E25PL4SSS	2000	BJ25EVSIC	2001	J25TESNF	2002
E25R4SSS	2000	BJ25EVLSIC	2001	J25TELSNF	2002
E25RL4SSS	2000	BJ25PL3SIE	2001	J25ELSTA	2003
E25TE4SSS	2000	BJ25VL3SIE	2001	J25RSTC	2003
BJ25ESSS	2000	J25ESIC	2001	J25RLSTC	2003
BJ25ELSSS	2000	J25ELSIC	2001	J25ESTR	2003
BJ25PL3SSB	2000	J25EVSIC	2001	J25TELSTR	2003
J25ESSS	2000	J25EVLSIC	2001	J25ELSRM	2004
J25ELSSS	2000	J25JRSIE	2001	J25GTESRS	2004
J25JRSSB	2000	J25PL3SIE	2001	J25PL4SRS	2004
J25JRTSSS	2000	J25R3SIE	2001	J25RSRR	2004
J25PL3SSB	2000	J25RL3SIE	2001	J25RLSRR	2004
J25R3SSB	2000	J25RSID	2001	J25TESRA	2004
J25RL3SSB	2000	J25RLSID	2001	J25TELSRA	2004
J25RSSE	2000	J25RV3SIE	2001	J25TEL4SRS	2004
J25RLSSE	2000	J25RVL3SIE	2001	J25ELSOB	2005
J25TEL3SSB	2000	J25RVSID	2001	J25E4SOS	2005
J25TESSD	2000	J25RVLSID	2001	J25EL4SOS	2005
J25TELSSD	2000	J25TESIS	2001	J25GTESOC	2005
SJ25RTSSB	2000	J25TELSIS	2001	J25R4SOS	2005
E25EL4SIC	2001	J25TEL3SIE	2001	J25RL4SOS	2005
E25FRSIS	2001	J25TVL3SIE	2001	J25RSOA	2005
E25PL4SIC	2001	J25TVSIS	2001	J25RLSOA	2005
E25R4SIC	2001	J25TVLSIS	2001	J25TESOM	2005
E25RL4SIC	2001	J25VL3SIE	2001	J25TELSOM	2005
E25TE4SIC	2001	SJ25RVTSIE	2001	J25TE4SOS	2005
E25TEL4SIC	2001	J25ELSNF	2002	J25TEL4SOS	2005
BJ25ESIC	2001	J25RSNF	2002		

30 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E30EL4SSS	2000	E30TE4SIC	2001	J30RSNF	2002
E30PL4SSS	2000	E30TEL4SIC	2001	J30RLSNF	2002
E30R4SSS	2000	BJ30ESIA	2001	J30ELSTB	2003
E25RL4SSS	2000	BJ30ELSIA	2001	J30RSTB	2003
E30TE4SSS	2000	BJ30EVSIA	2001	J30RLSTB	2003
BJ30ESSR	2000	BJ30EVLSIA	2001	J30ELSRE	2004
BJ30ELSSR	2000	J30ESIA	2001	J30PL4SRS	2004
J30ESSR	2000	J30ELSIA	2001	J30RSRE	2004
J30ELSSR	2000	J30EVSIA	2001	J30RLSRE	2004
J30RPSSR	2000	J30EVL3SIA	2001	J30TEL4SRS	2004
J30RPLSSSR	2000	J30RSIA	2001	J30ELSOD	2005
J30RSSR	2000	J30RLSIA	2001	J30PL4SOC	2005
J30RLSSR	2000	J30RPSIA	2001	J30RSOD	2005
E30EL4SIC	2001	J30RPLSIA	2001	J30RLSOD	2005
E30PL4SIC	2001	J30RV3SIA	2001	J30TEL4SOC	2005
E30R4SIC	2001	J30RVLSIA	2001		
E30RL4SIC	2001	J30ELSNF	2002		

RECREATIONAL OUTBOARDS 2000-2005

35 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
BJ35E3SSB	2000	BJ35EL3SIE	2001	J35R3SIE	2001
BJ35EL3SSB	2000	BJ35EV3SIE	2001	J35RL3SIE	2001
BJ35PL3SSB	2000	BJ35EVL3SIE	2001	J35PL3SIE	2001
J35PL3SSB	2000	BJ35PL3SIE	2001	J35TEL3SIE	2001
J35R3SSB	2000	BJ35RV3SIE	2001	J35TVL3SIE	2001
J35RL3SSB	2000	BJ35RV3SIE	2001	J35VL3SIE	2001
J35TEL3SSB	2000	BJ35RVL3SIE	2001		
BJ35E3SIE	2001	BJ35VL3SIE	2001		

40 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E40PL4SSC	2000	BJ40PLSIG	2001	J40PLSNF	2002
BJ40ESSM	2000	BJ40VLSIB	2001	J40PL4STA	2003
BJ40ELSSM	2000	BJ40VLSIG	2001	J40PLSTD	2003
BJ40PLSSM	2000	J30JRSIE	2001	J40RSTD	2003
J30JRSSB	2000	J40PLSIB	2001	J40RLSTD	2003
J40PLSSM	2000	J40PLSIG	2001	E40DELSRC	2004
J40RSSM	2000	J40RSIB	2001	E40DPLSRC	2004
J40RLSSM	2000	J40RSIG	2001	E40DRLSRC	2004
J40TPLSSM	2000	J40RLSIB	2001	BJ40PL4SRS	2004
E40FLSIS	2001	J40RLSIG	2001	J40PL4SRM	2004
E40FELSIS	2001	J40RVSIB	2001	J40PLSRS	2004
E40FRSIS	2001	J40RVSIG	2001	J40RSRS	2004
E40FRLSIS	2001	J40RVLSIB	2001	J40RLSRS	2004
E40PL4SIR	2001	J40RVLSIG	2001	E40DELSOR	2005
BJ40ESIB	2001	J40TPLSIB	2001	E40DPLSOR	2005
BJ40ESIG	2001	J40TPLSIG	2001	E40DRLSOR	2005
BJ40ELSIB	2001	J40TVLSIB	2001	BJ40PL4SOC	2005
BJ40ELSIG	2001	J40TVLSIG	2001	J40PL4SOB	2005
BJ40EVSIB	2001	J40VLSIB	2001	J40PLSOC	2005
BJ40EVSIG	2001	J40VLSIG	2001	J40RSOC	2005
BJ40EVLSIB	2001	J40RSNF	2002	J40RLSOC	2005
BJ40EVLSIG	2001	J40RLSNF	2002		
BJ40PLSIB	2001	J40PL4SNF	2002		

RECREATIONAL OUTBOARDS 2000-2005

50 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E50PL4SSC	2000	BJ50EVLSIG	2001	J50RVLSIG	2001
BJ50ESSA	2000	BJ50EVLSIM	2001	J50VLSIB	2001
BJ50ELSSA	2000	BJ50PLSIB	2001	J50VLSIG	2001
BJ50PLSSM	2000	BJ50PLSIG	2001	RJ50PLSIB	2001
BJ50RLSSM	2000	BJ50RLSIB	2001	RJ50PLSIG	2001
J50ELSSA	2000	BJ50RLSIG	2001	J50PL4SNF	2002
J50PLSSM	2000	BJ50RVLSIB	2001	J50PLSNF	2002
RJ50PLSSM	2000	BJ50RVLSIG	2001	J50PL4STA	2003
E50FLSIS	2001	BJ50VLSIB	2001	J50PLSTD	2003
E50FELSSIS	2001	BJ50VLSIG	2001	E50DPLSRC	2004
E50PL4SIR	2001	J50ELSIG	2001	BJ50PL4SRS	2004
BJ50ESIG	2001	J50ELSIM	2001	J50PL4SRM	2004
BJ50ESIM	2001	J50EVLSIG	2001	J50PLSRS	2004
BJ50ELSIG	2001	J50EVLSIM	2001	E50DPLSOR	2005
BJ50ELSIM	2001	J50PLSIB	2001	BJ50PL4SOC	2005
BJ50EVSIG	2001	J50PLSIG	2001	J50PL4SOB	2005
BJ50EVSIM	2001	J50RVLSIB	2001	J50PLSOC	2005

55 HP Models

Model Number	Year
J55RPLSSR	2000
J55RPLSIA	2001

60 HP Models

Model Number	Year
J40JPLSSR	2000
J60PLSSE	2000
E60FPLSIS	2001
J40JPLSIA	2001
J40JVLSIA	2001
J60PLSID	2001
J60VLSID	2001
J60PL4SNF	2002
BJ60PL4STC	2003
J60PL4STC	2003
BJ60PL4SRR	2004
J60PL4SRR	2004
E60DPLSOR	2005
BJ60PL4SOA	2005
J60PL4SOA	2005

70 HP Models

Model Number	Year
E70PL4SSR	2000
BJ70PLSSD	2000
J70PLSSD	2000
J70EPLSSR	2000
RJ70PLSSD	2000
E70FPLSIS	2001
E70PL4SIA	2001
BJ70PLSIS	2001
BJ70VLSIS	2001
J70EPLSIA	2001
J70PLSIS	2001
J70VLSIS	2001
RJ70PLSIS	2001
J70PL4SNF	2002
BJ70PL4STC	2003
J70PL4STC	2003
BJ70PL4SRR	2004
J70PL4SRR	2004
E70DPLSOS	2005
BJ70PL4SOA	2005
J70PL4SOA	2005

75 HP Models

Model Number	Year
E75FPLSSH	2000
RE75FPLSSH	2000
E75FPLSIC	2001
E75FPLSIF	2001
E75FPLSIG	2001
E75FSLSIC	2001
E75FSLSIF	2001
E75FSLSIG	2001
E75FSXSIF	2001
E75FSXSIG	2001
RE75FPLSIC	2001
RE75FPLSIF	2001
RE75FPLSIG	2001
RE75FSXSIF	2001
RE75FSXSIG	2001
E75FPLSNF	2002
E75FPLSTA	2003
E75DPLSRC	2004
E75DPLSOR	2005

RECREATIONAL OUTBOARDS 2000-2005

90 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E90FPLSSH	2000	BJ90PLSIF	2001	BJ90PX4STS	2003
E90FPLSSR	2000	BJ90PLSIG	2001	J90GLSTA	2003
RE90FPLSSH	2000	BJ90VLSIC	2001	J90PL4STS	2003
RE90FPLSSR	2000	BJ90VLSIF	2001	J90PLSTC	2003
BJ90PLSSE	2000	BJ90VLSIG	2001	J90PX4STS	2003
BJ90PXSSSE	2000	BJ90VXSIC	2001	E90DPLSRC	2004
BJ90VXSSS	2000	BJ90VXSIF	2001	E90DPXSRC	2004
J90PLSSE	2000	BJ90VXSIG	2001	E90DSLSRS	2004
J90SPLSSC	2000	J90PLSID	2001	BJ90PL4SRC	2004
J90VXSSS	2000	J90PLSIF	2001	BJ90PX4SRC	2004
RJ90PLSSE	2000	J90PLSIG	2001	J90GLSRM	2004
RJ90VLSSS	2000	J90VLSIC	2001	J90PL4SRC	2004
E90FPLSIA	2001	J90VLSIF	2001	J90PLSRR	2004
E90FPLSIF	2001	J90VLSIG	2001	J90PX4SRC	2004
E90FPLSIG	2001	RJ90PLSID	2001	J90PXSR	2004
E90FSLSIA	2001	RJ90PLSIF	2001	E90DPLSOR	2005
E90FSLSIF	2001	RJ90PLSIG	2001	E90DPXSOR	2005
E90FSLSIG	2001	RJ90VLSIC	2001	E90DSLSOC	2005
E90FSXSIF	2001	RJ90VLSIF	2001	BJ90PX4SOR	2005
E90FSXSIG	2001	RJ90VLSIG	2001	BJ90PL4SOR	2005
RE90FPLSIA	2001	E90FPLSNF	2002	J90GLSOB	2005
RE90FPLSIF	2001	J90PLSNF	2002	J90PL4SOR	2005
RE90FPLSIG	2001	J90VLSNF	2002	J90PLSOA	2005
RE90FSXSIF	2001	E90FPLSTB	2003	J90PX4SOR	2005
RE90FSXSIG	2001	E90FSLSTB	2003	J90PXSOC	2005
BJ90PLSID	2001	BJ90PL4STS	2003		

100 HP Models

Model Number	Year
E100FPLSRS	2004
E100FSLSRS	2004
E100FPLSOC	2005
E100FSLSOC	2005

RECREATIONAL OUTBOARDS 2000-2005

115 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E115FPLSSH	2000	RE115FSSIF	2001	E115FPXSNF	2002
E115FPLSSR	2000	RE115FSSIG	2001	J115PLSNF	2002
E115FPXSSH	2000	RE115FXSIA	2001	J115PXSIF	2002
E115FPXSSR	2000	RE115FXSIF	2001	J115VLSNF	2002
E115FSLSSH	2000	RE115FXSIG	2001	E115FPLSTB	2003
E115FSLSSR	2000	BJ115PLSIE	2001	E115FPXSTB	2003
RE115FLSSH	2000	BJ115PLSIF	2001	E115FSLSTB	2003
RE115FLSSR	2000	BJ115PLSIG	2001	BJ115L4STS	2003
RE115FXSSH	2000	BJ115VLSIC	2001	BJ115X4STS	2003
RE115FXSSR	2000	BJ115VLSIF	2001	J115GLSTA	2003
RE115FSSSR	2000	BJ115VLSIG	2001	J115PL4STS	2003
BJ115PLSSB	2000	BJ115VXSIC	2001	J115PLSTS	2003
BJ115PXSSB	2000	BJ115VXSIF	2001	J115PX4STS	2003
BJ115VXSSB	2000	BJ115VXSIG	2001	J115PXSTS	2003
J115JPLSSR	2000	J115JPLSIA	2001	E115FPLSRE	2004
J115SPLSSC	2000	J115JPLSIF	2001	E115FPXSRE	2004
J115PLSSB	2000	J115JPLSIG	2001	E115FSLSRE	2004
J115PXSSB	2000	J115PLSIE	2001	BJ115L4SRC	2004
J115VLSSB	2000	J115PLSIF	2001	BJ115X4SRC	2004
J115VXSSB	2000	J115PLSIG	2001	J115GLSRM	2004
RJ115PLSSB	2000	J115VLSIC	2001	J115PL4SRC	2004
RJ115PXSSB	2000	J115VLSIF	2001	J115PLSRC	2004
RJ115VLSSB	2000	J115VLSIG	2001	J115PX4SRC	2004
E115FPLSIA	2001	J115VXSIC	2001	J115PXSRC	2004
E115FPLSIF	2001	J115VXSIF	2001	E115FPLSOD	2005
E115FPLSIG	2001	J115VXSIG	2001	E115FPXSOD	2005
E115FPXSIA	2001	RJ115PLSIE	2001	E115FSLSOD	2005
E115FPXSIF	2001	RJ115PLSIF	2001	BJ115L4SOR	2005
E115FPXSIG	2001	RJ115PLSIG	2001	BJ115X4SOR	2005
E115FSLSIA	2001	RJ115VLSIC	2001	J115GLSOB	2005
E115FSLSIF	2001	RJ115VLSIF	2001	J115PL4SOR	2005
E115FSLSIG	2001	RJ115VLSIG	2001	J115PLSOR	2005
RE115FLSIA	2001	RJ115VXSIC	2001	J115PX4SOR	2005
RE115FLSIF	2001	RJ115VXSIF	2001	J115PXSOR	2005
RE115FLSIG	2001	RJ115VXSIG	2001		
RE115FSSIA	2001	E115FPLSNF	2002		

RECREATIONAL OUTBOARDS 2000-2005

<i>130 HP Models</i>	
Model Number	Year
BJ130PLSSS	2000
BJ130PXSSS	2000
BJ130VXSSS	2000
J130PLSSS	2000
J130PXSSS	2000
J130VXSSS	2000
RJ130PLSSS	2000
RJ130PXSSS	2000
RJ130VXSSS	2000

<i>135 HP Models</i>	
Model Number	Year
E135FCXSSS	2000
E135FPLSSS	2000
E135FSLSSS	2000
E135FSXSSS	2000
RE135FCSSS	2000
RE135FLSSS	2000
RE135FXSSS	2000
E135FCXSIF	2001
E135FCXSIG	2001
E135FPLSIF	2001
E135FPLSIG	2001
E135FSLSIF	2001
E135FSLSIG	2001
E135FSXSIF	2001
E135FSXSIG	2001
RE135FCSIF	2001
RE135FCSIG	2001
RE135FLSIF	2001
RE135FLSIG	2001
RE135FXSIF	2001
RE135FXSIG	2001
BJ135PLSIF	2001
BJ135VXSIF	2001
J135PLSIF	2001
J135VLSIF	2001
J135VXSIF	2001
RJ135PLSIF	2001
RJ135VXSIF	2001
E135FCXSNF	2002
E135FPLSNF	2002
E135FPXSNF	2002
E135FCXSTA	2003
E135FPLSTA	2003
E135FPLSTF	2003
E135FPXSTA	2003
E135FSLSTA	2003
E135FSLSTF	2003
E135FCXSRM	2004
E135FPLSRM	2004
E135FPXSRM	2004
E135FSLSRM	2004
E135FCXSOB	2005
E135FSLSOB	2005
E135FPLSOB	2005
E135FPXSOB	2005

<i>140 HP Models</i>	
Model Number	Year
J140CX4STS	2003
J140PL4STS	2003
J140PX4STS	2003
BJ140CX4RS	2004
BJ140L4SRS	2004
BJ140X4SRS	2004
J140CX4SRC	2004
J140PL4SRC	2004
J140PX4SRC	2004
BJ140CX4OC	2005
BJ140L4SOC	2005
BJ140X4SOC	2005
J140CX4SOR	2005
J140PL4SOR	2005
J140PX4SOR	2005

RECREATIONAL OUTBOARDS 2000-2005

150 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E150FCXSSM	2000	E150FSLSIG	2001	J150CXSNF	2002
E150FCXSSV	2000	RE150FCSIF	2001	J150PLSNF	2002
E150FPLSSM	2000	RE150FCSIG	2001	J150PXSNF	2002
E150FPLSSV	2000	RE150FHSIG	2001	J150VLSNF	2002
E150FPXSSM	2000	RE150FLSIF	2001	E150FCXSNF	2002
E150FPXSSV	2000	R150FLSIG	2001	E150FPLSNF	2002
E150FSLSSM	2000	RE150FSSIF	2001	E150FPXSNF	2002
E150FSLSSV	2000	RE150FSSIG	2001	E150FCXSTD	2003
RE150FCSSM	2000	RE150FXSIF	2001	E150FPLSTD	2003
RE150FCSSV	2000	RE150FXSIG	2001	E150FPLSTF	2003
RE150FLSSM	2000	J150JPLSIF	2001	E150FPXSTD	2003
RE150FLSSV	2000	J150JPLSIR	2001	E150FSLSTD	2003
RE150FXSSM	2000	J150JPLSIG	2001	E150FSLSTF	2003
RE150FXSSV	2000	J150PLSIF	2001	J150CXSTA	2003
RE150FSSSM	2000	J150PLSIR	2001	J150GLSTA	2003
J150CXSSC	2000	J150PLSIG	2001	J150GLSTF	2003
J150JPLSSC	2000	J150VCXSIC	2001	J150PLSTF	2003
J150PLSSS	2000	J150VCXSIF	2001	J150PLSTM	2003
J150PXSSS	2000	J150VCXSIG	2001	J150PXSTM	2003
J150SPLSSC	2000	J150VLSIC	2001	E150FCXSRS	2004
J150VCXSSS	2000	J150VLSIF	2001	E150FHLSRS	2004
J150VLSSS	2000	J150VLSIG	2001	E150FPLSRS	2004
J150VXSSS	2000	J150VXSIC	2001	E150FPXSRS	2004
RJ150CXSSC	2000	J150VXSIF	2001	E150FSLSRS	2004
RJ150PLSSS	2000	J150VXSIG	2001	J150CXSRM	2004
RJ150PXSSS	2000	RJ150PLSIF	2001	J150GLSRM	2004
RJ150VCSSS	2000	RJ150PLSIR	2001	J150PLSRB	2004
RJ150VLSSS	2000	RJ150PLSIG	2001	J150PXS RB	2004
RJ150VXSSS	2000	RJ150VCSIC	2001	E150FCXSOC	2005
E150FHLSIG	2001	RJ150VCSIF	2001	E150FHLSOC	2005
E150FCXSIF	2001	RJ150VCSIG	2001	E150FPLSOC	2005
E150FCXSIG	2001	RJ150VLSIC	2001	E150FPXSOC	2005
E150FPLSIF	2001	RJ150VLSIF	2001	E150FSLSOC	2005
E150FPLSIG	2001	RJ150VLSIG	2001	J150CXSOB	2005
E150FPXSIF	2001	RJ150VXSIC	2001	J150GLSOB	2005
E150FPXSIG	2001	RJ150VXSIF	2001	J150PLSOE	2005
E150FSLSIF	2001	RJ150VXSIG	2001	J150PXSOE	2005

RECREATIONAL OUTBOARDS 2000-2005

175 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E175FCXSSR	2000	RE175FCSIF	2001	J175PLSNF	2002
E175FCXSSV	2000	RE175FCSIG	2001	J175PXSNF	2002
E175FPLSSR	2000	RE175FLSIF	2001	J175VLSNF	2002
E175FPLSSV	2000	R175FLSIG	2001	E175FCXSNF	2002
E175FPXSSR	2000	RE175FSSIF	2001	E175FPLSNF	2002
E175FPXSSV	2000	RE175FSSIG	2001	E175FPXSNF	2002
E175FSLSSC	2000	RE175FXSIF	2001	E175FCXSTB	2003
E175FSLSSV	2000	RE175FXSIG	2001	E175FPLSTB	2003
RE175FCSSR	2000	BJ175PLSIF	2001	E175FPLSTF	2003
RE175FCSSV	2000	BJ175PLSIR	2001	E175FPXSTB	2003
RE175FLSSR	2000	BJ175PLSIG	2001	E175FSLSTF	2003
RE175FLSSV	2000	BJ175VXSIC	2001	E175FSLSTM	2003
RE175FSSSC	2000	BJ175VXSIF	2001	J175CXSTA	2003
RE175FXSSR	2000	BJ175VXSIG	2001	J175GLSTA	2003
RE175FXSSV	2000	J175PLSIF	2001	J175GLSTF	2003
BJ175PLSSC	2000	J175PLSIR	2001	J175PLSTF	2003
BJ175PXSSC	2000	J175PLSIG	2001	J175PLSTM	2003
BJ175VXSSS	2000	J175VCXSIC	2001	J175PXSTM	2003
J175PLSSC	2000	J175VCXSIF	2001	E175FCXSRE	2004
J175PXSSC	2000	J175VCXSIG	2001	E175FPLSRE	2004
J175VLSSS	2000	J175VLSIC	2001	E175FPXSRE	2004
J175VXSSS	2000	J175VLSIF	2001	E175FSLSRB	2004
J175CXSSC	2000	J175VLSIG	2001	J175CXSRM	2004
J175VCXSSS	2000	J175VXSIC	2001	J175GLSRM	2004
J175SPLSSC	2000	J175VXSIF	2001	J175PLSRB	2004
RJ175CXSSS	2000	J175VXSIG	2001	J175PXSRB	2004
RJ175PLSSC	2000	RJ175PLSIF	2001	E175FCXSOD	2005
RJ175VXSSS	2000	RJ175PLSIR	2001	E175FPLSOD	2005
E175FCXSIF	2001	RJ175PLSIG	2001	E175FPXSOD	2005
E175FCXSIG	2001	RJ175VCSIC	2001	E175FSLSOE	2005
E175FPLSIF	2001	RJ175VCSIF	2001	J175CXSOB	2005
E175FPLSIG	2001	RJ175VCSIG	2001	J175GLSOB	2005
E175FPXSIF	2001	RJ175VXSIC	2001	J175PLSOE	2005
E175FPXSIG	2001	RJ175VXSIF	2001	J175PXSOE	2005
E175FSLSIF	2001	RJ175VXSIG	2001		
E175FSLSIG	2001	J175CXSNF	2002		

RECREATIONAL OUTBOARDS 2000-2005

200 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E200FCXSSC	2000	E200FCXSIG	2001	RJ200PLSIF	2001
E200FCXSSH	2000	E200FCXSIR	2001	RJ200VXSIF	2001
E200FPLSSC	2000	E200FPLSIF	2001	E200FCXSNF	2002
E200FPLSSH	2000	E200FPLSIG	2001	E200FPLSNF	2002
E200FPXSSC	2000	E200FPLSIR	2001	E200FPXSNF	2002
E200FPXSSH	2000	E200FPXSIF	2001	E200FCXSTM	2003
E200FSLSSC	2000	E200FPXSIG	2001	E200FHLSTS	2003
E200FSLSSH	2000	E200FPXSIR	2001	E200FPLSTM	2003
RE200FCSSC	2000	E200FSLSIF	2001	E200FPXSTM	2003
RE200FCSSH	2000	E200FSLSIG	2001	E200FSLSTM	2003
RE200FLSSC	2000	E200FSLSIR	2001	E200FCXSRB	2004
RE200FLSSH	2000	RE200FCSIF	2001	E200FHLSRC	2004
RE200FXSSC	2000	RE200FCSIG	2001	E200FPLSRB	2004
RE200FXSSH	2000	RE200FCSIR	2001	E200FPXSRB	2004
RE200FSSSH	2000	RE200FLSIF	2001	E200FSLSRB	2004
BJ200CXSSC	2000	RE200FLSIG	2001	J200CX4SRS	2004
BJ200PLSSC	2000	RE200FLSIR	2001	J200PX4SRS	2004
BJ200PXSSC	2000	RE200FSSIF	2001	E200DCXSOC	2005
BJ200VCSSC	2000	RE200FSSIG	2001	E200DHLSOC	2005
BJ200VXSSC	2000	RE200FSSIR	2001	E200DPLSOC	2005
J200CXSSC	2000	RE200FXSIF	2001	E200DPXSOC	2005
J200PLSSC	2000	RE200FXSIG	2001	E200DSLLOC	2005
J200PXSSC	2000	RE200FXSIR	2001	E200FCXSOE	2005
J200VCSSC	2000	BJ200PLSIF	2001	E200FHLSOR	2005
J200VXSSC	2000	BJ200VCSIF	2001	E200FPLSOE	2005
RJ200PLSSC	2000	BJ200VXSIF	2001	E200FPXSOE	2005
RJ200PXSSC	2000	J200PLSIF	2001	E200FSLSOE	2005
RJ200VXSSC	2000	J200VCXSIF	2001	J200CX4SOC	2005
E200FCXSIF	2001	J200VXSIF	2001	J200PX4SOC	2005

RECREATIONAL OUTBOARDS 2000-2005

225 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E225FCXSSC	2000	E225FCXSIR	2001	RJ225HGSIF	2001
E225FCXSSH	2000	E225FCZSIF	2001	RJ225HLSIF	2001
E225FCZSSC	2000	E225FCZSIG	2001	RJ225PLSIF	2001
E225FCZSSH	2000	E225FCZSIR	2001	RJ225VXSIF	2001
E225FGLSSC	2000	E225FHLSIF	2001	E225FCXSNF	2002
E225FGLSSH	2000	E225FHLSIG	2001	E225FCZSNF	2002
E225FHLSSS	2000	E225FHLSIR	2001	E225FHLSNF	2002
E225FPLSSC	2000	E225FPLSIF	2001	E225FPLSNF	2002
E225FPLSSH	2000	E225FPLSIG	2001	E225FPXSNF	2002
E225FPXSSC	2000	E225FPLSIR	2001	E225FPZSNF	2002
E225FPXSSH	2000	E225FPXSIF	2001	E225FCXSTM	2003
E225FPZSSC	2000	E225FPXSIG	2001	E225FCZSTM	2003
E225FPZSSH	2000	E225FPXSIR	2001	E225FHLSTA	2003
RE225FHSSS	2000	E225FPZSIF	2001	E225FPLSTM	2003
RE225FCSSC	2000	E225FPZSIG	2001	E225FPXSTM	2003
RE225FCSSH	2000	E225FPZSIR	2001	E225FPZSTM	2003
RE225FGLSSC	2000	RE225FCSIF	2001	E225FCXSRB	2004
RE225FGLSSH	2000	RE225FCSIG	2001	E225FCZSRB	2004
RE225FLSSC	2000	RE225FCSIR	2001	E225FHLSRM	2004
RE225FLSSH	2000	RE225FHSIF	2001	E225FHXSRS	2004
RE225FXSSC	2000	RE225FHSIG	2001	E225FPLSRB	2004
RE225FXSSH	2000	RE225FHSIR	2001	E225FPXSRB	2004
RE225FZSSH	2000	RE225FLSIF	2001	E225FPZSRB	2004
BJ225CXSSR	2000	RE225FLSIG	2001	J225CX4SRS	2004
BJ225PLSSR	2000	RE225FLSIR	2001	J225PX4SRS	2004
BJ225PXSSR	2000	RE225FXSIF	2001	E225DCXSOC	2005
BJ225VCSSS	2000	RE225FXSIG	2001	E225DCZSOC	2005
BJ225VXSSS	2000	RE225FXSIR	2001	E225DHLSOC	2005
J225HGLSSC	2000	RE225FZSIF	2001	E225DHXSOS	2005
J225HPLSSC	2000	RE225FZSIG	2001	E225DPLSOC	2005
J225CXSSR	2000	RE225FZSIR	2001	E225DPXSOC	2005
J225PLSSR	2000	BJ225PLSIF	2001	E225DPZSOC	2005
J225PXSSR	2000	BJ225VCSIF	2001	E225FCXSOE	2005
J225VCXSSS	2000	BJ225VXSIF	2001	E225FCZSOE	2005
J225VXSSS	2000	J200VLSIF	2001	E225FHLSOB	2005
RJ225CXSSS	2000	J225HGLSIF	2001	E225FHXSOC	2005
RJ225HGSSC	2000	J225HPLSIF	2001	E225FPLSOE	2005
RJ225HLSSC	2000	J225HVLSIF	2001	E225FPXSOE	2005
RJ225PLSSR	2000	J225PLSIF	2001	E225FPZSOE	2005
RJ225PXSSR	2000	J225VCXSIF	2001	J225CX4SOC	2005
RJ225VXSSS	2000	J225VLSIF	2001	J225CZ4SOS	2005
E225FCXSIF	2001	J225VXSIF	2001	J225PX4SOC	2005
E225FCXSIG	2001	RJ225CXSIG	2001	J225PZ4SOS	2005

RECREATIONAL OUTBOARDS 2000-2005

250 HP Models

Model Number	Year	Model Number	Year	Model Number	Year
E250FCXSSS	2000	E250FCZSIC	2001	E250FCXSTA	2003
E250FCZSSS	2000	E250FCZSIF	2001	E250FCZSTA	2003
E250FGLSSS	2000	E250FCZSIG	2001	E250FPLSTR	2003
E250FPLSSS	2000	E250FPXSIC	2001	E250FPXSTA	2003
E250FPXSSS	2000	E250FPXSIF	2001	E250FPZSTA	2003
E250FPZSSS	2000	E250FPXSIG	2001	E250FCXSRM	2004
J250CXSSC	2000	E250FPZSIC	2001	E250FCZSRM	2004
J250CZSSC	2000	E250FPZSIF	2001	E250FPLSRA	2004
J250PXSSS	2000	E250FPZSIG	2001	E250FPXSRM	2004
J250PZSSS	2000	J250VCXSIF	2001	E250FPZSRM	2004
J250VCXSSS	2000	J250VCZSIF	2001	E250DCXSOC	2005
J250VCZSSS	2000	J250VXSIF	2001	E250DCZSOC	2005
J250VXSSS	2000	J250VZSIF	2001	E250DPLSOC	2005
J250VZSSS	2000	RJ250CXSF	2001	E250DPXSOC	2005
RJ250CXSSS	2000	RJ250VXSIF	2001	E250DPZSOC	2005
RJ250VXSSS	2000	RJ250VZSIF	2001	E250FCXSOB	2005
RJ250VZSSS	2000	E250FCXSNF	2002	E250FCZSOB	2005
E250FCXSIC	2001	E250FCZSNF	2002	E250FPLSOM	2005
E250FCXSIF	2001	E250FPXSNF	2002	E250FPXSOB	2005
E250FCXSIG	2001	E250FPZSNF	2002	E250FPZSOB	2005

COMMERCIAL OUTBOARDS 1977-1999

2.3 HP Models

Model Number	Year
H2RSP	1991
H2RSH	1992
H2RSB	1993
H2RST	1994
H2RSY	1995
H2RSA	1996
H2RSK	1997
2RSS / 2RSL	1998
2WREE	1999

3.3 HP Models

Model Number	Year
H3RSP	1991
H3RSH	1992
H3RSB	1993
H3RST	1994
H3RSY	1995
H3RSA	1996
H3RSK	1997
3RSS / 3RSL	1998
3WREE	1999

4 HP Models

Model Number	Year
4RST / 4RSLT	1981
4RSY / 4RSLY	1982

6 HP Models

Model Number	Year
6RS78B / 6RSL78B	1978
6834B	1978
6835B	1978
6K79S / 6KL79S	1979
6RS79E / 6RSL79E	1979
6912S	1979
6913S	1979
6934E	1979
6935E	1979
6KCCSC	1980
6KCLCSC	1980
6RSCSD / 6RSLCSD	1980
6KCH / 6KCLH	1981-82
6RSM / 6RSLM	1981-82
6KCB / 6KCLB	1983
6RSZ / 6RSLZ	1983
6KCT / 6KCLT	1984

6.5 HP Models

Model Number	Year
7RSF / 7RSLF	1981
7RSQ / 7RSLQ	1982
7RSV / 7RSLV	1983
7RSP / 7RSLP	1984
7RSH / 7RSLH	1985
7RSB / 7RSLB	1986
7RST / 7RSLT	1987
7RSY / 7RSLY	1988
7RSA / 7RSLA	1989
7RSK / 7RSLK	1990
7RSS / 7RSL	1991
7RSG / 7RSLG	1992
7RSW / 7RSLW	1993

8 HP Models

Model Number	Year
8RCV / 8RCLV	1994
8RCP / 8RCLP	1995
8RCH / 8RCLH	1996
8RCB / 8RCLB	1997
8RCT / 8RCLT	1998
8WREE / 8WRLEE	1999

9 HP Models

Model Number	Year
9R78S / 9RL78S	1978
9RXL78S	1978
9800S	1978
9802S	1978
9803S	1978
9K79S / 9KL79S	1979
9KXL79S	1979
9R79C-R	1979
9RL79C-R	1979
9RXL79R	1979
9900R	1979
9902C-R	1979
9903C-R	1979
9910S	1979
9912S	1979
9913S	1979
9KCCSC	1980
9KCLCSC	1980
9KCXCSC	1980
9RSCSA	1980
9RSLCSA	1980
9RSXCSCA	1980

10 HP Models

Model Number	Year
10RSG-2 / 10RSLG-2	1981
10RSW / 10RSLW	1982
10RSC / M	1983
10RSLC / M	1983
10RSYC / M	1983
10RSYZ	1984
10RSZ / 10RSLZ	1984
10RSD / 10RSLD	1985
10RSYD	1985
10RSR / 10RSLR	1986
10RSYR	1986
10KCC / 10KCLC	1987
10KSLC	1987
10RSE / 10RSE	1987
10RSU / 10RSLU	1988
10KCLZ	1989
10RSJ / 10RSLJ	1989
10KCLD	1990
10RSN / 10RSLN	1990
10RPF / 10RPLF	1991
10RSF / 10RSLF	1991
10RPO / 10RPLO	1992
10RPV / 10RPLV	1993
10RPP / 10RPLP	1994
10RPH / 10RPLH	1995
10RPB / 10RPLB	1996
10RPT / 10RPLT	1997
10RPY / 10RPLY	1998

11 HP Models

Model Number	Year
11KCA / 11KCLA	1983
11KCS / 11KCLS	1984
11KCG / 11KCLG	1985
11KCW / 11KCLW	1986
11KSLW / 11KSYW	1986

COMMERCIAL OUTBOARDS 1977-1999

<i>12 HP Models</i>	
Model Number	Year
12R78S / 12RL78S	1978
12RXL78S	1978
12800S	1978
12802S	1978
12803S	1978
12K79S / 12KL79S	1979
12KXL79S	1979
12R79C-R	1979
12RL79C-R	1979
12RXL79R	1979
12900R	1979
12902C-R	1979
12903C-R	1979
12910S	1979
12912S	1979
12913S	1979
12KCCSC	1980
12KCLCSC	1980
12KCXCSC	1980
12RSCSA	1980
12RSLCSA	1980
12RSXCSA	1980

<i>14 HP Models</i>	
Model Number	Year
14RSR-2	1981
14RSLR-2	1981
14RSE / 14RSLE	1982
14RSU-J	1983
14RSLU-J	1983
14RSYU-J	1983
14RSN / 14RSLN	1984
14RSYN	1984
14RSF / 14RSLF	1985
14RSYF	1985
14RSQ / 14RSLQ	1986
14RSYQ	1986
14RSV / 14RSLV	1987
14RSP / 14RSLP	1988
14RSH / 14RSLH	1989
14RSB / 14RSLB	1990
14RST / 14RSLT	1991

<i>15 HP Models</i>	
Model Number	Year
15RSP / 15RSLP	1982
15RSH / 15RSB	1983
15RSLH / 15RSLB	1983
15RPT / 15RPLT	1991
15RPY / 15RPLY	1992
15RPA / 15RPLA	1993
15RPK / 15RPLR	1994
15RSG / 15RSLG	1994
15KCJ / 15KCLJ	1995
15RPS / 15RPLS	1995
15RSW / 15RSLW	1995
15KCN / 15KCLN	1996
15RPG / 15RPLG	1996
15KCF / 15KCLF	1997
15RPW / 15RPWL	1997
15KCO / 15KCLO	1998
15RPC / 15RPLC	1998
15WREE / 15WRLEE	1999

<i>25 HP Models</i>	
Model Number	Year
25RS78C / 25RSL78C	1978
25832C	1978
25833C	1978
25RS79R / 25RSL79R	1979
25932R	1979
25933R	1979
25RSCSA / 25RSLCSA	1980
25RSA / 25RSLA	1981
25RWCI / 25RWLCI	1981
25RPH / 25RPLH	1982
25RSK / 25RSLK	1982
25RWCN / 25RWLCN	1982
25RSS / 25RSLS	1983
25RWCT / 25RWLCT	1983
25RPB / 25RPLB	1984
25RSG-2 / 25RSLG-2	1984
25RSYG / 2	1984
25RWCR / 25RWLCR	1984
25KCS / 25KCLS	1985
25RSW / 25RSLW	1985
25RSYW	1985
25RWCO / 25RWLCO	1985
25KCG / 25KCLG	1986
25RSC / 25RSLC	1986
25RSYC	1986
25RWCD / 25RWLCD	1986
25KCW / 25KCLW	1987
25RSM / 25RSLM	1987

25RSYM	1987
25RWCU / 25RWLCU	1987
25KCLC	1988
25RSYZ	1988
25RSZ / 25RSLZ	1988
25RWA / 25RWLA	1988
25RPD	1989
25RSD / 25RSLD	1989
25RSYD	1989
25RWK / 25RWLK	1989
25RPR	1990
25RSR / 25RSLR	1990
25RWES / 25RWLES	1990
25RPE	1991
25RPLE	1991
25RSE / 25RSLE	1991
25RWEI / 25RWLEI	1991
25RPU / 25RPLU	1992
25RSLU	1992
25RWEN / 25RWLEN	1992
25RPJ / 25RPLJ	1993
25RSLJ	1993
25RWET / 25RWLET	1993
25RPN / 25RPLN	1994
25RSLN	1994
25RWER / 25RWLER	1994
25FPF	1995
25RPF / 25RPLF	1995
25RSLF	1995
25RWEO / 25RWLEO	1995
25FPO	1996
25RPO / 25RPLO	1996
25RSLO	1996
25RWED / 25RWLED	1996
25FPV	1997
25RPV / 25RPLV	1997
25RSLV	1997
25RWEU / 25RWLEU	1997
25RPP / 25RPLP	1998
25WREE / 25WRLEE	1999

<i>35 HP Models</i>	
Model Number	Year
35RSP / 35RSLP	1981
35RSH / 35RSLH	1982
35RWEC / 35RWLEC	1998

COMMERCIAL OUTBOARDS 1977-1999

40 HP Models	
Model Number	Year
40R77M / 40RL77M	1977
40704M / 40705M	1977
40R78B / 40RL78B	1978
40804B	1978
40805B	1978
40R79E / 40RL79E	1979
40904E	1979
40905E	1979
40RSCSD	1980
40RSLCSD	1980
40RSD / R	1981
40RSLD / R	1981
40RWCI / 40RWLCI	1981
40RWCN / 40RWLCN	1982
40RSR / 40RSLR	1982-83
40RCV / 40RCLV	1983
40RCYV	1983
40RWCT / 40RWLCT	1983
40RCP / 40RCLP	1984
40RCYP	1984
40RWCR / 40RWLCR	1984
40RCH / 40RCLH	1985
40RCYH	1985
40RWCO / 40RWLCO	1985
40RCB / 40RCLB	1986
40RCYB	1986
40RWCD / 40RWLCD	1986
40RCT / 40RCLT	1987
40RCYT	1987
40RCY / 40RCLY	1988
40RCYY	1988
40RCA / 40RCLA	1989
40RCYA	1989
40RCK / 40RCLK	1990
40RCYK	1990
40RSS / 40RSLS	1991
40RSYS	1991
40RSG / 40RSLG	1992
40RSYG	1992
40RPO / 40RPLO	1993
40RPYO	1993
40RSW / 40RSLW	1993
40RSYW	1993
40RPV / 40RPLV	1994
40RPYV	1994
40RSC / 40RSLC	1994
40RSYC	1994
40RWLS	1994
40RPP / 40RPLP	1995

40RPYP	1995
40RSM / 40RSLM	1995
40RSYM	1995
40RWLG	1995
40RPH / 40RPLH	1996
40RPYH	1996
40RSLZ	1996
40RPB / 40RPLB	1997
40RPYB	1997
40RSLD	1997
40RPT / 40RPLT	1998
40RPYT	1998
40RSLR	1998
40WREE / 40WRLEE	1999
40WRYEE	1999

45 HP Models	
Model Number	Year
45RSYZ	1985
45RSZ / 45RSLZ	1985
45RWZ / 45RWLZ	1985
45RCCD / 45RCLCD	1986
45RSD / 45RSLD	1986
45RSYD	1986
45RWD / 45RWLD	1986
45RWYD	1986
45RCCU / 45RCLCU	1987
45RSR / 45RSLR	1987
45RSYR	1987
45RWLR / 45RWYR	1987
45RCR / 45RCLR	1988
45RSE / 45RSLE	1988
45RSYE	1988
45RWLE / 45RWYE	1988
45RCE / 45RCLE	1989
45RSU / 45RSLU	1989
45RSYU	1989
45RWLU / 45RWYU	1989
45WMLE	1989
45RCES / 45RCLES	1990
45RSJ / 45RSLJ	1990
45RSYJ	1990
45RWLJ / 45RWYJ	1990
45WMLES	1990
45RCEI / 45RCLEI	1991
45RSN / 45RSLN	1991
45RSYN	1991
45RWLN / 45RWYN	1991
45WMLEI	1991
45RCEN / 45RCLEN	1992
45RSF / 45RSLF	1992

45RSYF	1992
45RWLF / 45RWYF	1992
45WMLEN	1992
45RCET / 45RCLET	1993
45RSO / 45RSLO	1993
45RSYO	1993
45RCER / 45RCLER	1994
45RSV / 45RSLV	1994
45RSYV	1994
45RCEO / 45RCLEO	1995
45RSP / 45RSLP	1995
45RSYP	1995
45RCLED	1996
45RSLH	1996
45KCV / 45KCLV	1997
45RCLEU	1997
45RSLB	1997

50 HP Models	
Model Number	Year
50R77D / 50RL77D	1977
50RS77S / 50RSL77S	1977
50702D / 50703D	1977
50732S / 50733S	1977
50R78SG	1978
50RL78SG	1978
50RS78C-G	1978
50RSL78C-G	1978
50802SG	1978
50803SG	1978
50832C-G	1978
50833C-G	1978
50R79C	1979
50RL79C	1979
50RS79R / 50RSL79R	1979
50902C	1979
50903C	1979
50932R	1979
50933R	1979

55 HP Models	
Model Number	Year
55R79S / 55RL79S	1979
55902S / 55903S	1979
55RLCS	1980
55RSCS / 55RSLCS	1980
55RCI / 55RLCI	1981
55RSU / 55RSLU	1981
55RCN / 55RLCN	1982
55RSJ / 55RSLJ	1982
55RCT / 55RLCT	1983

COMMERCIAL OUTBOARDS 1977-1999

55RSN / 55RSLN	1983
55RSYN	1983
55RSF / 55RSLF	1984
55RSYF	1984
55RWCR / 55RWLCR	1984
55AWQ / 55AWLQ	1985
55RSQ / 55RSLQ	1985
55RSYQ	1985
55RWLCO	1985
55RSV / 55RSLV	1986
55RSYV	1986
55RWLCD	1986
55RSP / 55RSLP	1987
55RSYP	1987
55RWLCU	1987
55RSH / 55RSLH	1988
55RSYH	1988
55RWLR	1988
55RSB / 55RSLB	1989
55RSYB	1989
55RWLE	1989
55RST / 55RSLT	1990
55RSYT	1990
55RWLES	1990
55RSY / 55RSLY	1991
55RSYY	1991
55RWLEI	1991
55RSA / 55RSLA	1992
55RSYA	1992
55RWLEN	1992
55RSK / 55RSLK	1993
55RSYK	1993
55RWLET	1993
55RSS / 55RSLS	1994
55RSYS	1994
55RWLER	1994
55WMLW	1994
55RSG / 55RSLG	1995
55RSYG	1995
55WMLC	1995
55RSW / 55RSLW	1996
55RSYW	1996
55WMLM	1996
55RSC / 55RSLC	1997
55RSYC	1997
55WMLZ	1997
55RSM / 55RSLM	1998
55RSYM	1998
55WMLD	1998
55WREE / 55WRLEE	1999
55WRYEE	1999

65 HP Models

Model Number	Year
65RSLV / 65RSYV	1984
65RWLCR	1984
65TELCR	1984
65WTLCR	1984
65RSLP / 65RSYP	1985
65RWLCO	1985
65TELCO	1985
65WMLCO	1985
65WMLP / 65WMYP	1985
65WTLCO	1985
65RSLH / 65RSYH	1986
65RWLCD	1986
65TELCD	1986
65WMLCD	1986
65WMLH / 65WMYH	1986
65RSLB / 65RSYB	1987
65WMLB / 65WMYB	1987
65WMLCU	1987
65RSLT / 65RSYT	1988
65WMLM	1988
65WMLT / 65WMYT	1988
65RSLY / 65RSYY	1989
65WMLY / 65WMYV	1989
65WMLZ	1989
65RSLA / 65RSYA	1990
65WMLA / 65WMYA	1990
65WMLISM	1990
65RSLK / 65RSYK	1991
65WMLIEI	1991
65WMLK / 65WMYK	1991
65RSLS / 65RSYS	1992
65WMLLEN	1992
65WMLS / 65Wmys	1992
65RSLG / 65RSYG	1993
65WMLLET	1993
65WMLG / 65WMYG	1993
65RSLW / 65RSYW	1994
65WMLER	1994
65WMLW / 65WMYW	1994
65RSLC / 65RSYC	1995
65WMLC / 65WMYC	1995
65WMLLEO	1995
65RSLM / 65RSYM	1996
65WMLM / 65WMYM	1996
65RSLZ / 65RSYZ	1997
65WMLZ / 65WMYZ	1997
65RSLD / 65RSYD	1998
65WMLD / 65WMYD	1998
65WELEE	1999
65WRLEE / 65WRYEE	1999

100 HP Models

Model Number	Year
100WMLCR	1984
100WMPLV	1984
100WTLCR	1984
100WTPLV	1984
100WMLCO	1985
100WMPLP	1985
100WTLCO	1985
100WTPLP	1985
100TEMLH / 100TEMXH	1986
100WMLCD	1986
100WMPLH	1986
100WTLCD / 100WTXCD	1986
100WTPLH	1986
100WMPLB	1987
100WTLCU / 100WTXCU	1987
100WTPLB	1987
100WMPLT	1988
100WTLM / 100WTXM	1988
100WTPLT	1988
100WMPLY	1989
100WT LZ / 100WTXZ	1989
100WTPLY	1989
100WMPLA	1990
100WTLES / 100WTXES	1990
100WTPLA	1990
100WMPLK	1991
100WTLEI / 100WTXEI	1991
100WTPLK	1991
100WMPLS	1992
100WTLEN / 100WTXEN	1992
100WTPLS	1992
100WMPLG	1993
100WTLET / 100WTXET	1993
100WTPLG	1993
100WMPLW	1994
100WTLER / 100WTXER	1994
100WTPLW	1994
100WMPLC	1995
100WTLEO / 100WTXEO	1995
100WTPLC	1995
100WMPLM	1996
100WTLED / 100WTXED	1996
100WTPLM	1996
100WMPLZ	1997
100WTLEU / 100WTXEU	1997
100WTPLZ	1997
100WQLEC / 100WQXEC	1998
100WPLEE / 100WPXEE	1999

COMMERCIAL OUTBOARDS 1977-1999

105 HP Models

Model Number	Year
105RWLP / 105RWYP	1997
105RWLH / 105RWYH	1998
105WELV / 105WEXV	1998
105WRPLV	1998
105WELEE	1999
105WPLEE / 105WPXEE	1999
105WRLEE / 105WRYEE	1999

125 HP Models

Model Number	Year
125RWLS / 125RWXS	1987
125RWYS	1987
125WTPLS / 125WTPXS	1987
125RWLG / 125RWXG	1988
125RWYG	1988
125WTPLG / 125WTPXG	1988
125ESXW	1989
125RWLW / 125RWYW	1989
125WTPLW	1989
125WTPXW	1989
125ESXES	1990
125RWLC / 125RWYC	1990
125WTPLC / 125WTPXC	1990
125RWLM / 125RWYM	1991
125WTPLM / 125WTPXM	1991
125ESXEN	1992
125RWLZ / 125RWYZ	1992
125WTPLZ / 125WTPXZ	1992
125ESXET	1993
125RWLDF	1993
125RWYDF	1993
125WTPLDF	1993
125WTPXDF	1993
125ESXER	1994
125RWLR / 125RWYR	1994
125WTPLK / 125WTPXK	1994
125WTPLR / 125WTPXR	1994
125RWLE / 125RWYE	1995
125WTPLE / 125WTPXE	1995
125RWYU	1996
125WTPLU / 125WTPXU	1996
125RWYJ	1997
125WTPLJ / 125WTPXJ	1997
125RWYN	1998
125WTPLN / 125WTPXN	1998

150 HP Models

Model Number	Year
150WTLET / 150WTXET	1993
150WTPL / 150WTPX	1993
150WTPLV / 150WTPXV	1993
150WCLER	1994
150WTLER / 150WTXR	1994
150WTPLP / 150WTPXP	1994
150WTPLV / 150WTPXV	1994
150WTLEO / 150WTXEO	1995
150WTLO / 150WTXO	1995
150WTPLH / 150WTPXH	1995
150WTLD / 150WTD	1996
150WTPLB / 150WTPXB	1996
150WCLUA	1997
150WTLUA / 150WTXUA	1997
150WTPLTZ	1997
150WTPXTZ	1997
150WTPLY / 150WTPXY	1998
150WPLEE	1999

155 HP Models

Model Number	Year
155WTLCR / 155WTXCR	1984
155WTPLV / 155WTPXV	1984
155WTLCO / 155WTXCO	1985
155WTPLP / 155WTPXP	1985
155WTLCD / 155WTXCD	1986
155WTPLH / 155WTPXH	1986
155WTLCU / 155WTXCU	1987
155WTPLB / 155WTPXB	1987
155WTLM / 155WTXM	1988
155WTPLT / 155WTPXT	1988
155WTALY	1989
155WTLZ / 155WTXZ	1989
155WTPLY / 155WTPXY	1989
155WTALA	1990
155WTLES / 155WTXES	1990
155WTPLA / 155WTPXA	1990
155WTLER / 155WTXER	1991
155WTPLK / 155WTPXK	1991
155WTLER / 155WTXER	1992
155WTPLS / 155WTPXS	1992

200 HP Models

Model Number	Year
200WTPLV / 200WTPXV	1990
200WTPLP / 200WTPXP	1991
200WTPLH / 200WTPXH	1992
200WTPLB / 200WTPXB	1993
200WTPLK / 200WTPXK	1994
200WTPLT / 200WTPXT	1994
200WTPLY / 200WTPXY	1995
200WTPLA / 200WTPXA	1996
200WTPLS / 200WTPXS	1997
200WTPLG / 200WTPXG	1998
200WPXEE	1999

COMMERCIAL OUTBOARDS 2000-2005

2.3 HP Models

Model Number	Year
E2WRSSC	2000
J2WRSSC	2000
E2WRSIR	2001
J2WRSIR	2001

3 HP Models

Model Number	Year
E3WRSSC	2000
J3WRSSC	2000

3.5 HP Models

Model Number	Year
E3WRSIR	2001
J3WRSIR	2001

8 HP Models

Model Number	Year
E8WRSSC	2000
E8WRLSSC	2000
J8WRSSC	2000
J8WRLSSC	2000
E8WRSIR	2001
E8WRLSIR	2001
J8WRSIR	2001
J8WRLSIR	2001

15 HP Models

Model Number	Year
E15WRSSC	2000
E15WRLSSC	2000
J15WRSSC	2000
J15WRLSSC	2000
E15WRSIR	2001
E15WRLSIR	2001
J15WRSIR	2001
J15WRLSIR	2001
J15WRSRM	2004
J15WRLSRM	2004
J15RTSOS	2005
J15WRSOB	2005
J15WRLSOB	2005

25 HP Models

Model Number	Year
E25WRSSC	2000
E25WRLSSC	2000
J25WRSSC	2000
J25WRLSSC	2000
E25WRSIR	2001
E25WRLSIR	2001
J25WRSIR	2001
J25WRLSIR	2001
J25WRSRM	2004
J25WRLSRM	2004
J25RTSOS	2005
J25WRSOB	2005
J25WRLSOB	2005

40 HP Models

Model Number	Year
E40WRSSC	2000
E40WRLSSC	2000
E40WRYSSC	2000
J40WRSSC	2000
J40WRLSSC	2000
J40WRYSSC	2000
E40WRSIR	2001
E40WRLSIR	2001
E40WRYIR	2001
J40WRSIR	2001
J40WRLSIR	2001
J40WRYISIR	2001
J40OILSRS	2004

55 HP Models

Model Number	Year
E55WRSSC	2000
E55WRLSSC	2000
E55WRYSSC	2000
J55WRSSC	2000
J55WRLSSC	2000
J55WRYSSC	2000
J55WRVLSIR	2001
E55WRSIR	2001
E55WRLSIR	2001
E55WRYIR	2001
J55WRSIR	2001
J55WRLSIR	2001
J55WRYISIR	2001
J55WRLSTM	2003
J55WRLSRB	2004
J55WRLSRG	2004
J55WRYSRM	2004
J55WRLSOE	2005
J55WRYSOB	2005

60 HP Models

Model Number	Year
E60WDRLSOS	2005
E60WDYRSOS	2005

65 HP Models

Model Number	Year
E65WELSSC	2000
E65WRLSSC	2000
E65WRYSSC	2000
J65WELSSC	2000
J65WRLSSC	2000
J65WRYSSC	2000
E65WELSIR	2001
E65WRLSIR	2001
E65WRYISIR	2001
J65WELSIR	2001
J65WRLSIR	2001
J65WRYISIR	2001

COMMERCIAL OUTBOARDS 2000-2005

90 HP Models

Model Number	Year
E90WDELSOS	2005
E90WDPLSOS	2005
E90WDRLSOS	2005
E90WDRXSOS	2005

100 HP Models

Model Number	Year
E100WPLSSR	2000
E100WPXSSR	2000
J100WPLSSR	2000
J100WPXSSR	2000
E100WPLSIA	2001
E100WPLSIF	2001
E100WPLSIG	2001
E100WPXSIA	2001
E100WPXSIF	2001
E100WPXSIG	2001
J100WPLSIA	2001
J100WPLSIF	2001
J100WPLSIG	2001
J100WPXSIA	2001
J100WPXSIF	2001
J100WPXSIG	2001

105 HP Models

Model Number	Year
E105WELSSC	2000
E105WPLSSC	2000
E105WPXSSC	2000
E105WRLSSC	2000
E105WRYSSC	2000
J105WELSSC	2000
J105WPLSSC	2000
J105WPXSSC	2000
J105WRLSSC	2000
J105WRYSSC	2000
E105WELSIF	2001
E105WELSIR	2001
E105WPLSIF	2001
E105WPLSIG	2001
E105WPLSIR	2001
E105WPXSIF	2001
E105WPXSIG	2001
E105WPXSIR	2001
E105WRLSIR	2001
E105WRYSIR	2001
J105WELSIF	2001
J105WELSIR	2001
J105WPLSIF	2001
J105WPLSIG	2001
J105WPLSIR	2001
J105WPXSIF	2001
J105WPXSIG	2001
J105WPXSIR	2001
J105WRLSIR	2001
J105WRYSIR	2001
J105WPLSTM	2003

115 HP Models

Model Number	Year
J115WPLSRS	2004
J115WPLSOC	2005

150 HP Models

Model Number	Year
E150WPLSSC	2000
J150WPLSSC	2000
E150WPLSIF	2001
E150WPLSIR	2001
E150WPLSIG	2001
J150WPLSIF	2001
J150WPLSIR	2001
J150WPLSIG	2001

200 HP Models

Model Number	Year
E200WPXSSC	2000
J200WPXSSC	2000
E200WPXSIF	2001
J200WXSIF	2001
J200WPXSIF	2001

MILITARY OUTBOARDS 1980-2005

Model Number	HP	Year	Model Number	HP	Year
AEM25A	25	1980	70RNLIB	70	1996
AEM25B	25	1988	J150MXSSD	150	2000
J30MLSTS	30	2003	J150MXSIF	150	2001
J30MLSRC	30	2004	J150MXSIS	150	2001
J30MLSOR	30	2005	J150MXSIG	150	2001
AM35A	35	1983	J150MLSTS	150	2003
AM35B / AML35B	35	1985	J150MXSTS	150	2003
AM35BI / AML35BI	35	1987	J150MLSRC	150	2004
AM35C / AML35C	35	1990	J150MXSRC	150	2004
AM35CI / AML35CI	35	1991	J150MLSOR	150	2005
AML35D	35	1995-96	J150MXSOR	150	2005
J40MLSTS	40	2003	J175MXSTS	175	2003
50RNLIA	50	1990	J175MXSRC	175	2004
50RNLIB	50	1992	J175MXSOR	175	2005
50RNLIC	50	1994	U200CMXED	200	1996
J55APRLSIS	55	2001	U200MMXED	200	1996
J55APRLSNF	55	2002	200CMXEU	200	1997
J55APRLSTR	55	2003	200MMXEU	200	1997
J55MLSTS	55	2003	200CMXEC	200	1998
J55APRLSRA	55	2004	200MMXEC	200	1998
J55APRLSRG	55	2004	U250CMXED	250	1996
J55MLSRC	55	2004	U250MMXED	250	1996
J55MLSRG	55	2004	250CMXEU	250	1997
J55APRLSOM	55	2005	250MMXEU	250	1997
J55MLSOR	55	2005	250CMXEC	250	1998
70RNLIA	70	1994	250MMXEC	250	1998

RACING OUTBOARDS 1967-1995

Model Number	HP/Engine		Model Number	HP/Engine	
	Design	Year		Design	Year
55842S	55	1968	KT-16E	15A	1992
60042C	60	1970	NR-19S	200	1976
65342M	65	1973	OSL-JS	V8	1987
75612S	75	1976	OSLR-JS	V8	1987
75632S	75	1976	OSX-JS	V8	1987
115042R	115	1970	OSXR-JS	V8	1987
115742S	115	1967	OZF-ES	V8	1984-86
115842S	115	1968	OZF-JS	V8	1984-86
135342M	135	1973	RT-10S	45SS	1986
200612S	200	1976	RTE-11C	45SS	1987
FI-ES	V8	1986	RTE-12R	45SS	1988
FI-JS	V8	1986	RTE-13A	45SS	1989
FR-19S	75	1976	RTE-14M	45SS	1990
FR-31M	75	1988	RTE-16E	45SS	1992
FT-10S	55	1968	RTE-17D	45SS	1993
FT-12C	60	1970	RTE-20R	45SS	1996
FT-16B	65	1973	SST60-15B	SST60	1991
FT-19S	75	1976	SST60-16E	SST60	1992
GT-10S	115	1968	SST60-17D	SST60	1993
KC-13R	115	1970	SST60-19F	SST60	1995
KR-15M	135	1973	SST100-15B	SST100	1991
KT-10S	15A	1986	SST100-16E	SST100	1992
KT-11C	15A	1987	SST100-17D	SST100	1993
KT-12R	15A	1988	SST100-19F	SST100	1995
KT-13A	15A	1989	SSTE-13A	SST60	1989
KT-14M	15A	1990	SSTE-14M	SST60	1990

ELECTRIC OUTBOARDS 1974-1999

Model Number	Length	Battery	Year	Model Number	Length	Battery	Year
E2BS	36"	12V	1974-76	BF4P	36"	24V	1984
EB12S	36"	12V	1974-76	BFL2P	42"	12V	1984
E2TS	36"	12V	1975-76	BFL4P	42"	24V	1984
E4BS	36"	24V	1975-76	BH4P	36"	24V	1984
E4TS	36"	24V	1975-76	TH2P	36"	12V	1984
EB14S	36"	24V	1975-76	BF2H	36"	12V	1985
ET12S	36"	12V	1975-76	BF4H	36"	24V	1985
ET14S	36"	24V	1975-76	BFL2H	42"	12V	1985
EB52B	36"	12V	1977-82	BFL4H	42"	24V	1985
EB54M	36"	24V	1977-82	BHL4H	42"	24V	1985
EB82B	36"	12V	1977-82	TH2H	36"	12V	1985
EB84M	36"	24V	1977-81	BF2B	36"	12V	1986
E25	36"	12V	1977-82	BF2TB	36"	12V	1986
E28	36"	12V	1977-82	BF4B	36"	24V	1986
E45	36"	24V	1977-82	BFL2TB	42"	12V	1986
E48C	36"	24V	1977-79	BFL4B	42"	24V	1986
BH4S	36"	24V	1980	BH2TB	36"	12V	1986
E4HS	36"	24V	1980	BHL2TB	42"	12V	1986
E48R	36"	24V	1980	TH2B	36"	12V	1986
BH4C	36"	24V	1981	BF2T	36"	12V	1987
E4HC	36"	24V	1981	BF2TT	36"	12V	1987
E48A	36"	24V	1981	BF4T	36"	24V	1987
EBL52B	42"	12V	1981	BFL2TT	42"	12V	1987
EBL84M	42"	24V	1981	BFL4T	42"	24V	1987
EL25B	42"	12V	1981	BH2TT	36"	12V	1987
EL48A	42"	24V	1981	BHL2TT	42"	12V	1987
E4HR-A	36"	24V	1982	BHL4T	42"	24V	1987
E25E-D	36"	12V	1982	TH2T	36"	12V	1987
E28E-D	36"	12V	1982	BF2TY	36"	12V	1988
E45M-B	36"	24V	1982	BF2Y	36"	12V	1988
EB52E-D	36"	12V	1982	BF4Y	36"	24V	1988
EB54B-E	36"	24V	1982	BFL2TY	42"	12V	1988
EB82E-D	36"	12V	1982	BFL4Y	42"	24V	1988
EBH4R-A	36"	24V	1982	BH2TY	36"	12V	1988
EBL52E-D	42"	12V	1982	BHL2TY	42"	12V	1988
EBL84B-G	42"	24V	1982	BHL4Y	42"	24V	1988
EL25E-D	42"	12V	1982	TH2Y	36"	12V	1988
EL48M-G	42"	24V	1982	BF2A-BF2Y	36"	12V	1989-90
BF2V	36"	12V	1983	BF2TA-Y	36"	12V	1989-90
BF4V	36"	24V	1983	BF4A-BF4Y	36"	24V	1989-90
BFL2V	42"	12V	1983	BFL2TA-Y	42"	12V	1989-90
BH4V	36"	24V	1983	BFL4A-Y	42"	24V	1989-90
BL84-G	42"	24V	1983	BFX2TA-Y	48"	12V	1989-90
E2TC	36"	12V	1983	BFX4A-Y	48"	24V	1989-90
EL48-G	42"	24V	1983	BH2TA-Y	36"	12V	1989-90
ET12-C	36"	12V	1983	BHL2TA-Y	42"	12V	1989-90
ET12C	36"	12V	1983	BHL4A-Y	42"	24V	1989-90
BF2P	36"	12V	1984	TH2A-TH2Y	36"	12V	1989-90

ELECTRIC OUTBOARDS 1974-1999

Model Number	Length	Battery	Year
BF2K	36"	12V	1990-94
BF2TK	36"	12V	1990-94
BF4K	36"	24V	1990-94
BF4TK	36"	24V	1990-94
BFL2TK	42"	12V	1990-94
BFL4K	42"	24V	1990-94
BFL4TK	42"	24V	1990-94
BFX2TK	48"	12V	1990-94
BFX4K	48"	24V	1990-94
BFX4TK	48"	24V	1990-94
BH2TK	36"	12V	1990-94
BHL2TK	42"	12V	1990-94
BHL4K	42"	24V	1990-94
BHL4TK	42"	24V	1990-94
TH2K	36"	12V	1990-94
TH4TK	36"	24V	1990-94
TH2TK	36"	12V	1991-94
HBF2K	36"	12V	1992-97
BF2S	36"	12V	1994-97
BF2TS	36"	12V	1994-97
BF4PV	36"	24V	1994-97
BF4S	36"	24V	1994-97
BF4TS	36"	24V	1994-97
BFL2TS	42"	12V	1994-97
BFL4S	42"	24V	1994-97
BFL4TS	42"	24V	1994-97
BFX2TS	48"	12V	1994-97
BFX4S	48"	24V	1994-97
BFX4TS	48"	24V	1994-97
BH2TS	36"	12V	1994-97
BHL2TS	42"	12V	1994-97
BHL4S	42"	24V	1994-97
BHL4TS	42"	24V	1994-97
HBFL2K	42"	24V	1994-97
TH2TS	36"	12V	1994-97
TH4TS	36"	24V	1994-97
BF4TPV	36"	24V	1995-97
BFL4PV	42"	24V	1995-97
BFL4TPV	42"	24V	1995-97
BFX4PV	48"	24V	1995-97
BFX4TPV	48"	24V	1995-97
TH2TSS	28"	12V	1996-97
BF2G	36"	12V	1998
BF2TG	36"	12V	1998
BF4PP	36"	24V	1998
BF4TPP	36"	24V	1998
BFL2TG	42"	12V	1998

Model Number	Length	Battery	Year
BFL4PP	42"	24V	1998
BFL4TPP	42"	24V	1998
BFX2TG	48"	12V	1998
BFX4PP	48"	24V	1998
BFX4TPP	48"	24V	1998
BH2TG	36"	12V	1998
BHL2TG	42"	12V	1998
BHL4G	42"	24V	1998
BHL4TG	42"	24V	1998
HBF2S	36"	12V	1998
HBFL2S	42"	12V	1998
TH2TG	36"	12V	1998
TH2TSG	28"	12V	1998
TH4TG	36"	24V	1998
BF2TW	36"	12V	1999
BF2W	36"	12V	1999
BF4PH	36"	24V	1999
BF4TPH	36"	24V	1999
BFL2PD	48"	12V	1999
BFL2TW	42"	12V	1999
BFL4PH	42"	24V	1999
BFL4TM	52"	24V	1999
BFL4TPH	42"	24V	1999
BFX2TW	48"	12V	1999
BFX4PH	48"	24V	1999
BFX4TPH	48"	24V	1999
BH2TW	36"	12V	1999
BHL2TW	42"	12V	1999
BHL4TW	42"	24V	1999
BHL4W	42"	24V	1999
H2T	30"	12V	1999
H2TS	36"	12V	1999
H2TT	36"	12V	1999
H4TS	36"	24V	1999
HB4TS	52"	24V	1999
HBF2G	36"	12V	1999
HBFL2G	42"	12V	1999
TH2TSW	28"	12V	1999
TH2TW	36"	12V	1999
TH4TW	36"	24V	1999

PREFIX
B = Bow Mount
F = Foot Control
H = Hand Control
T = Transom Mount

ELECTRIC OUTBOARDS 1999-2001

Model Number	Length	Battery	Year
EFC 42F (P/N 773165)	48"	12V	1999-2001
EFC 54F (P/N 773177)	54"	24V	1999-2001
Intruder 36F (P/N 773169)	42"	12V	1999-2001
Intruder 44F (P/N 773171)	52"	12V	1999-2001
Intruder 44FP (P/N 773172)	42"	12V	1999-2001
Intruder 44H (P/N 773176)	52"	12V	1999-2001
Intruder 54FP (P/N 773174)	52"	24V	1999-2001
Intruder 54FPL (P/N 773175)	52"	24V	1999-2001
Intruder 54HP (P/N 773173)	52"	24V	1999-2001
Intruder 74FP (P/N 773166)	42"	24V	1999-2001

Model Number	Length	Battery	Year
Intruder 74HP (P/N 773168 & 773178)	52"	24V	1999-2001
Scout 30H (P/N 773161)	30"	12V	1999-2001
Scout 40H (P/N 773162)	36"	12V	1999-2001
SeaQuest 36H (P/N 773163)	36"	12V	1999-2001
SeaQuest 70H (P/N 773164)	36"	24V	1999-2001
SeaQuest 74HP (P/N 773167)	52"	24V	1999-2001
EFC 5S (P/N 770384)	48"	12V	2000-2001
EFC 55AS (P/N 770385)	48"	12V	2000-2001
EFC 65 (P/N 770386)	54"	24V	2000-2001
EFC 65AS (P/N 770387)	54"	24V	2000-2001

JOHNSON RECREATIONAL OUTBOARDS 1922-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
A	2	1922-24	FD-14	18	1960	JWF-21	3	1967
A-25	2	1925-26	FD-15	18	1961	JWF-23	3	1968
A-35	2.5	1927-28	FD-16	18	1962	K-35	6	1927
A-45	3	1929	FD-17	18	1963	K-40	7.15	1928
A-50	4	1930-32	FD-18	18	1964	K-45	7.15	1929
A-65	4.1	1933	FD-19	18	1965	K-50	8	1930-32
A-70	4.1	1934	FD-20	20	1966	K-65	9.2	1933
A-75	4.5	1935	FD-21	20	1967	K-70	9.2	1934
A-80	4.5	1936	FD-22	20	1968	K-75	9.3	1935
AA-37	4.5	1937	HA-10	2.5	1940	K-80	9.3	1936
AB-25	2	1925-26	HA-15	2.5	1940	KA-10	9.8	1940
AD-10	7.5	1956	HA-39	2.5	1939	KA-37	9.3	1937
AD-11	7.5	1957	HD-10	2.5	1940	KA-38	9.3	1938
AD-12	7.5	1958	HD-15	2.5	1940	KA-39	9.8	1939
AT-10	5	1940	HD-20	2.5	1941-42	KD-15	9.8	1941-48
AT-39	5	1939	HD-25	2.5	1946-50	KR-38 (RACING)		1938
BN	2	1922-24	HD-26	2.5	1951	KR-40 (RACING)		1928
CD-10	5.5	1954	HD-39	2.5	1939	KR-55 (RACING)		1931-37
CD-11	5.5	1954	HS-10	2.5	1940	KS-15	9.8	1941-42
CD-12	5.5	1955	HS-15	2.5	1940	LD-10	5	1965
CD-13	5.5	1956	HS-20	2.5	1941-42	LD-11	5	1966
CD-14	5.5	1957	J-25	1.5	1925-32	LD-12	5	1967
CD-15	5.5	1958	J-65	1.4	1933	LD-13	5	1968
CD-16	5.5	1959	J-70	1.4	1934	LS-37	2.1	1937
CD-17	5.5	1960	J-75	1.4	1935	LS-38	2.1	1938
CD-18	5.5	1961	J-80	1.7	1936	LT-10	5	1940
CD-19	5.5	1962	JH-19	3	1964	LT-37	4.2	1937
CD-20	5.5	1963	JH-20	3	1965	LT-38	4.2	1938
CD-21	5.5	1964	JH-21	3	1966	LT-39	5	1939
CD-22	6	1965	JH-22	3	1967	MD-15	1.5	1940
CD-23	6	1966	JH-23	3	1968	MD-20	1.5	1941-42
CD-24	6	1967	JHF-21	3	1967	MD-38	1.1	1938
CD-25	6	1968	JHF-22	3	1967	MD-39	1.1	1939
DS-37	2.1	1937	JHF-23	3	1968	MQ-10	9.5	1964
DS-38	2.1	1938	JW-10	3	1952-54	MQ-11	9.5	1965
DT-10	5	1940	JW-11	3	1955	MQ-12	9.5	1966
DT-37	4.2	1937	JW-12	3	1956	MQ-13	9.5	1967
DT-38	4.2	1938	JW-13	3	1957	MQ-14	9.5	1968
DT-39	5	1939	JW-14	3	1958	MS-15	1.5	1940
E-10	15	1956	JW-15	3	1959	MS-20	1.5	1941-42
E-11	18	1957	JW-16	3	1960	MS-38	1.1	1938
E-12	18	1958	JW-17	3	1961-62	MS-39	1.1	1939
F-70	3.3	1934	JW-18	3	1963	OA-55	3	1931
F-75	3.3	1935	JW-19	3	1964	OA-60	3	1932
FD-10	15	1956	JW-20	3	1965	OA-65	2.8	1933
FD-11	18	1957	JW-21	3	1966	OB-65	2.8	1933
FD-12	18	1958	JW-22	3	1967	OB-70	2.8	1934
FD-13	18	1959	JW-23	3	1968	OK-55	8	1931

JOHNSON RECREATIONAL OUTBOARDS 1922-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
OK-60	7	1932	RD-21	35	1959	S-70	13.3	1934
OK-75	8.1	1935	RD-22	40	1960	SA-50	13.3	1930-32
P-30	6	1926	RD-23	40	1961	SC-10	1.5	1968
P-35	8	1927	RD-24	40	1962	SD-10	16	1940-42
P-40	13.15	1928	RD-25	40	1963	SD-15	16	1946-48
P-45	12	1929	RD-26	40	1964	SD-20	16	1949-50
P-50	20	1930-32	RD-27	40	1965	SE-50	13.3	1930-32
P-65	21.4	1933	RD-28	40	1966	SR-38 (RACING)		1938
P-70	21.4	1934	RD-29	40	1967	SR-45	16	1929
P-75	22	1935	RD-30	40	1968	SR-50	16	1930
P-80	22	1936	RDE-16	25	1954	SR-55	18	1931
PA-50	20	1930-32	RDE-17	25	1955	SR-60 (RACING)		1932
PE-50	20	1930-32	RDE-18	30	1956	TD-15	5	1941-42
PO-10	22	1940	RDE-19	35	1957	TD-20	5	1946-49
PO-15	22	1941-50	RDE-19C	35	1958	TN-25	5	1950-51
PO-37	22	1937	RDS-20	35	1958	TN-26	5	1950-51
PO-38	22	1938	RDS-21	35	1959	TN-27	5	1950-51
PO-39	22	1939	RDS-22	40	1960	TN-28	5	1952-53
PR-40	16.5	1928	RDS-23	40	1961	TR-10	55	1968
PR-50	24	1930	RDS-24	40	1962	TR-40	25.75	1928-29
PR-55	27	1931	RDS-25	40	1963	TS-15	5	1941-42
PR-60	27	1932	RDS-26	40	1964	TS-20	5	1946
PR-65	27	1933	RDS-27	40	1965	V-45	26	1929-32
QD-10	10	1949-50	RDS-28	40	1966	V-65	26.1	1933
QD-11	10	1949-50	RDS-29	40	1967	V-70	26.1	1934
QD-12	10	1951-52	RDS-30	40	1968	VA-50	26.1	1930-32
QD-13	10	1951-52	RJE-18	30	1956	VE-50	26.1	1930-32
QD-14	10	1953	RJE-19	35	1957	VR-45	32	1929
QD-15	10	1954	RK-24	40	1962	VR-50	32	1930
QD-16	10	1955	RK-25	40	1963	VR-55	36	1931
QD-17	10	1956	RK-26	40	1964	VX-10	60	1964
QD-18	10	1957	RK-27	40	1965	VX-11	60	1965
QD-19	10	1958	RK-28	40	1966	VX-12	60	1966
QD-20	10	1959	RK-29	40	1967	VX-13	60	1967
QD-21	10	1960	RK-30	40	1968	VX-14	65	1968
QD-22	10	1961	RX-10	28	1962	VXH-10	60	1964
QD-23	10	1962	RX-11	28	1963	VXH-11	60	1965
QD-24	10	1963	RX-12	28	1964	VXH-12	60	1966
RD-10	25	1951	RX-13	33	1965	VXH-13	60	1967
RD-11	25	1951	RX-14	33	1966	VXH-14	65	1968
RD-12	25	1952	RX-15	33	1967	V4-10	50	1958
RD-13	25	1952	RX-16	33	1968	V4-11	50	1959
RD-14	25	1953	RXE-11	28	1963	V4A-13	75	1961
RD-15	25	1953-54	RXE-12	28	1964	V4A-14	75	1962-63
RD-16	25	1954	RXE-13	33	1965	V4A-15	75	1962-63
RD-17	25	1955	RXE-14	33	1966	V4A-16	75	1964
RD-18	30	1956	RXE-15	33	1967	V4A-17	75	1965
RD-19	35	1957	RXE-16	33	1968	V4A-18	80	1966
RD-19C	35	1958	S-45	13	1929-32	V4A-19	80	1967
RD-20	40	1958	S-65	13.3	1933	V4A-20	85	1968

JOHNSON RECREATIONAL OUTBOARDS 1922-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
V4H-16	75	1964	4B70	4	1970	6R71 / 6RL71	6	1971
V4H-17	75	1965	4BA74 / 4BAL74	4	1974	6R72 / 6RL72	6	1972
V4H-18	75	1966	4BA75 / 4BAL75	4	1975	6R73 / 6RL73	6	1973
V4M-10	90	1964	4BA76 / 4BAL76	4	1976	6R74 / 6RL74	6	1974
V4M-11	90	1965	4BA77 / 4BAL77	4	1977	6R75 / 6RL75	6	1975
V4ML-12	100	1966	4BA78 / 4BAL78	4	1978	6R76 / 6RL76	6	1976
V4S-10	50	1958	4BA79 / 4BAL79	4	1979	6R77 / 6RL77	6	1977
V4S-11	50	1959	4BR71	4	1971	6R78 / 6RL78	6	1978
V4S-12	75	1960	4BR72 / 4BRL72	4	1972	6R79 / 6RL79	6	1979
V4S-13	75	1961	4BR73 / 4BRL73	4	1973	8RCI / 8RLCI	7.5	1981
V4S-14	75	1962	4BR74 / 4BRL74	4	1974	8RCN / 8RLCN	7.5	1982
V4S-15	75	1963	4BR75 / 4BRL75	4	1975	8RCS / 8RLCS	7.5	1980
V4S-16	75	1964	4BR76 / 4BRL76	4	1976	8RCT / 8RLCT	7.5	1983
V4S-17	75	1965	4BR77 / 4BRL77	4	1977	9R69 / 9RL69	9.5	1969
V4S-18	80	1966	4BR78 / 4BRL78	4	1978	9R70 / 9RL70	9.5	1970
V4S-19	80	1967	4BR79 / 4BRL79	4	1979	9R71 / 9RL71	9.5	1971
V4S-20	85	1968	4BW71	4	1971	9R72 / 9RL72	9.5	1972
V4T-13	100	1967	4R69 / 4RL69	4	1969	9R73 / 9RL73	9.5	1973
V4T-14	100	1968	4R70 / 4RL70	4	1970	10BA74 / 10BAL74	9.9	1974
V4TL-13	100	1967	4R71 / 4RL71	4	1971	10BA75 / 10BAL75	9.9	1975
V4TL-14	100	1968	4R72	4	1972	10BA76 / 10BAL76	9.9	1976
WH-11	15	1965	4R73	4	1973	10BA77 / 10BAL77	9.9	1977
WH-12	15	1966	4R74	4	1974	10BA78 / 10BAL78	9.9	1978
WH-13	15	1967	4R75	4	1975	10BA79 / 10BAL79	9.9	1979
WH-14	15	1968	4R76	4	1976	10E74 / 10EL74	9.9	1974
WS-10	60	1965	4R77	4	1977	10E75 / 10EL75	9.9	1975
WS-11	60	1966	4R78 / 4RL78	4	1978	10E76 / 10EL76	9.9	1976
WS-12	60	1967	4R79 / 4RL79	4	1979	10E77 / 10EL77	9.9	1977
WS-13	60	1968	4W69	4	1969	10E78 / 10EL78	9.9	1978
XR-55 (RACING)		1931	4W70 / 4WL70	4	1970	10E79 / 10EL79	9.9	1979
100	1.7	1936	4W71 / 4WL71	4	1971	10R74 / 10RL74	9.9	1974
110	1.7	1937	4W72	4	1972	10R75 / 10RL75	9.9	1975
200	3.3	1936	4W73	4	1973	10R76 / 10RL76	9.9	1976
210	3.3	1937	4W74	4	1974	10R77 / 10RL77	9.9	1977
300	3.7	1935	4W75	4	1975	10R78 / 10RL78	9.9	1978
1R69	1.5	1969	4W76	4	1976	10R79 / 10RL79	9.9	1979
1R70	1.5	1970	4W77	4	1977	10SEL78	9.9	1978
2R71	2	1971	4W78	4	1978	10SEL79	9.9	1979
2R72	2	1972	4W79	4	1979	15BA74 / 15BAL74	15	1974
2R73	2	1973	6BR73 / 6BRL73	6	1973	15BA75 / 15BAL75	15	1975
2R74	2	1974	6BA74 / 6BAL74	6	1974	15BA76 / 15BAL76	15	1976
2R75	2	1975	6BA75 / 6BAL75	6	1975	15BA77 / 15BAL77	15	1977
2R76	2	1976	6BA76 / 6BAL76	6	1976	15BA78 / 15BAL78	15	1978
2R77	2	1977	6BA77 / 6BAL77	6	1977	15BA79 / 15BAL79	15	1979
2R78	2	1978	6BA78 / 6BAL78	6	1978	15E74 / 15EL74	15	1974
2R79	2	1979	6BG78 / 6BGL78	6	1978	15E75 / 15EL75	15	1975
3B10	3	1961	6BA79 / 6BAL79	6	1979	15E76 / 15EL76	15	1976
3B11	3	1962	6BG79 / 6BGL79	6	1979	15E77 / 15EL77	15	1977
3B12	3	1963	6R69 / 6RL69	6	1969	15E78 / 15EL78	15	1978
4B69	4	1969	6R70 / 6RL70	6	1970	15E79 / 15EL79	15	1979

JOHNSON RECREATIONAL OUTBOARDS 1922-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
15R74 / 15RL74	15	1974	25R78 / 25RL78	25	1978	50R73 / 50RL73	50	1973
15R75 / 15RL75	15	1975	25R79 / 25RL79	25	1979	50R75 / 50RL75	50	1975
15R76 / 15RL76	15	1976	33E69 / 33EL69	33	1969	50R77 / 50RL77	50	1977
15R77 / 15RL77	15	1977	33E70 / 33EL70	33	1970	50R78 / 50RL78	50	1978
15R78 / 15RL78	15	1978	33E71F / 33EL71F	33	1971	50R79 / 50RL79	50	1979
15R79 / 15RL79	15	1979	33R69 / 33RL69	33	1969	55E76 / 55EL76	55	1976
20B70 / 20BL70	20	1970	33R70 / 33RL70	33	1970	55E77 / 55EL77	55	1977
20BR73 / 20BRL73	20	1973	33R71F / 33RL71F	33	1971	55E78 / 55EL78	55	1978
20BA74 / 20BAL74	20	1974	35BA76 / 35BAL76	35	1976	55E79 / 55EL79	55	1979
20BA75 / 20BAL75	20	1975	35BA77 / 35BAL77	35	1977	55ES69 / 55ESL69	55	1969
20BA76 / 20BAL76	20	1976	35BA78 / 35BAL78	35	1978	55ETL77	55	1977
20BA77 / 20BAL77	20	1977	35BA79 / 35BAL79	35	1979	55ETL78	55	1978
20BF78 / 20BFL78	20	1978	35E76 / 35EL76	35	1976	55ETL79	55	1979
20BF79 / 20BFL79	20	1979	35E77 / 35EL77	35	1977	55R76 / 55RL76	55	1976
20CR78 / 20CRL78	20	1978	35E78 / 35EL78	35	1978	55R79 / 55RL79	55	1979
20CR79 / 20CRL79	20	1979	35E79 / 35EL79	35	1979	60ES70 / 60ESL70	60	1970
20R69 / 20RL69	20	1969	35R76 / 35RL76	35	1976	60ES71 / 60ESL71	60	1971
20R70 / 20RL70	20	1970	35R77 / 35RL77	35	1977	65ES72 / 65ESL72	65	1972
20R71 / 20RL71	20	1971	35R78 / 35RL78	35	1978	65ES73 / 65ESL73	65	1973
20R72 / 20RL72	20	1972	35R79 / 35RL79	35	1979	65ESLR72	65	1972
20R73 / 20RL73	20	1973	40BA74 / 40BAL74	40	1974	65ESR73 / 65ESLR	65	1973
25BA74 / 25BAL74	25	1974	40BA75 / 40BAL75	40	1975	70EL76	70	1976
25BA75 / 25BAL75	25	1975	40BA76 / 40BAL76	40	1976	70EL77 / 70ETL77	70	1977
25BA76 / 25BAL76	25	1976	40E69 / 40EL69	40	1969	70EL78 / 70ETL78	70	1978
25BA77 / 25BAL77	25	1977	40E70 / 40EL70	40	1970	70EL79 / 70ETL79	70	1979
25BA78 / 25BAL78	25	1978	40E71 / 40EL71	40	1971	70ESLR74	70	1974
25BA79 / 25BAL79	25	1979	40E72 / 40EL72	40	1972	70ES74 / 70ESL74	70	1974
25BE78 / 25BEL78	25	1978	40E73 / 40EL73	40	1973	70ES75 / 70ESL75	70	1975
25BE79 / 25BEL79	25	1979	40E74 / 40EL74	40	1974	75BER79	75	1979
25BF77 / 25BFL77	25	1977	40E75 / 40EL75	40	1975	75ER76 / 75ELR76	75	1976
25BF78 / 25BFL78	25	1978	40E76 / 40EL76	40	1976	75ER77 / 75ELR77	75	1977
25BF79 / 25BFL79	25	1979	40ES69 / 40ESL69	40	1969	75ER78 / 75ELR78	75	1978
25BR73 / 25BRL73	25	1973	40ES70 / 40ESL70	40	1970	75ER79 / 75ELR79	75	1979
25E72 / 25EL72	25	1972	40ES71 / 40ESL71	40	1971	75ESR75 / 75ESLR	75	1975
25E73 / 25EL73	25	1973	40R69 / 40RL69	40	1969	75ETLR77	75	1977
25E74 / 25EL74	25	1974	40R70 / 40RL70	40	1970	75ETLR78	75	1978
25E75 / 25EL75	25	1975	40R71 / 40RL71	40	1971	75ETLR79	75	1979
25E76 / 25EL76	25	1976	40R72 / 40RL72	40	1972	85EL76	85	1976
25E77 / 25EL77	25	1977	40R73 / 40RL73	40	1973	85EL77	85	1977
25E78 / 25EL78	25	1978	40R74 / 40RL74	40	1974	85ESL69	85	1969
25E79 / 25EL79	25	1979	40R75 / 40RL75	40	1975	85ESL70	85	1970
25R69 / 25RL69	25	1969	40R76 / 40RL76	40	1976	85ESL71	85	1971
25R70 / 25RL70	25	1970	40R77 / 40RL77	40	1977	85ESL72	85	1972
25R71 / 25RL71	25	1971	40R79 / 40RL79	40	1979	85ESL73	85	1973
25R72 / 25RL72	25	1972	50ES71 / 50ESL71	50	1971	85ESL74	85	1974
25R73 / 25RL73	25	1973	50ES72 / 50ESL72	50	1972	85ESL75	85	1975
25R74 / 25RL74	25	1974	50ES73 / 50ESL73	50	1973	85ETLR76	85	1976
25R75 / 25RL75	25	1975	50ES74 / 50ESL74	50	1974	85ETLR77	85	1977
25R76 / 25RL76	25	1976	50ES75 / 50ESL75	50	1975	85ETLR78	85	1978
25R77 / 25RL77	25	1977	50R72 / 50RL72	50	1972	85ML78	85	1978

JOHNSON RECREATIONAL OUTBOARDS 1922-1979

Model Number	HP	Year	Model Number	HP	Year
85ML79	85	1979	175TL77	175	1977
85TL79	85	1979	175TL78	175	1978
85TXLR77	85	1977	175TL79	175	1979
85TXLR78	85	1978	175TXL77	175	1977
85TXL79	85	1979	175TXL78	175	1978
100ESL71	100	1971	175TXL79	175	1979
100ESL72	100	1972	200TL76	200	1976
100ML79	100	1979	200TL77	200	1977
100TLR79	100	1979	200TL78	200	1978
100TXLR79	100	1979	200TL79	200	1979
115EL76	115	1976	200TXL76	200	1976
115EL77	115	1977	200TXL77	200	1977
115ESL69	115	1969	200TXL78	200	1978
115ESL70	115	1970	200TXL79	200	1979
115ESL73	115	1973	235TL78	235	1978
115ESL74	115	1974	235TL79	235	1979
115ESL75	115	1975	235TXL78	235	1978
115ETL74	115	1974	235TXL79	235	1979
115ETL75	115	1975			
115ETL76	115	1976			
115ETL77	115	1977			
115ETL78	115	1978			
115ML78	115	1978			
115ML79	115	1979			
115TL79	115	1979			
115TXL77	115	1977			
115TXL78	115	1978			
115TXL79	115	1979			
125ESL71	125	1971			
125ESL72	125	1972			
135EL76	135	1976			
135ESL73	135	1973			
135ESL74	135	1974			
135ESL75	135	1975			
135ETL74	135	1974			
135ETL75	135	1975			
135ETL76	135	1976			
140ML77	140	1977			
140ML78	140	1978			
140ML79	140	1979			
140TL77	140	1977			
140TL78	140	1978			
140TL79	140	1979			
140TXL77	140	1977			
140TXL78	140	1978			
140TXL79	140	1979			
150TL78	150	1978			
150TL79	150	1979			
150TXL78	150	1978			
150TXL79	150	1979			

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
A (#3000 / 7200)	3.5	1915-22	49B66 / 49B67	4	1979	205B62 / 205B63	20	1975
A (#50,000 and UP)	2	1915-28	52T	7	1925	206B62 / 206B63	20	1976
A (TWIN)	3	1923	62T	7	1926	207B62 / 207B63	20	1977
AA	4	1916-17	63B36 / 63B37	6	1973	208BF62 / 208BF63	20	1978
B (#5000 / 7200)	3.5	1915-22	64B66 / 64B67	6	1974	208CR02 / 208CR03	20	1978
B (#55,000 and UP)	2	1915-28	65B66 / 65B67	6	1975	209BF62 / 209BF63	20	1979
B (TWIN)	3	1923	66B66 / 66B67	6	1976	209CR02 / 209CR03	20	1979
C	2	1916	67B66 / 67B67	6	1977	253B02 / 253B03	25	1973
C (TWIN)	3	1924-25	68B66 / 68B67	6	1978	254B62 / 254B63	25	1974
D	2	1916	68BG66 / 68BG67	6	1978	255B62 / 255B63	25	1975
D (TWIN)	3	1924-25	69B66 / 69B67	6	1979	256B62 / 256B63	25	1976
E	3.5	1915	69BG66 / 69BG67	6	1979	257B62 / 257B63	25	1977
EE	4	1916	72T	7	1927	257BF02 / 257BF03	25	1977
F (#F1001-F4000)	6	1928	82A	7	1928	258B62 / 258B63	25	1978
F (#1F001-4F300)	7	1929	82B	11	1928	258BE52 / 258BE53	25	1978
G	4	1926	92A	7	1929	258BF62 / 258BF63	25	1978
H (#H1001-H2500)	12	1928	92B	14	1929	259B62 / 259B63	25	1979
H (#1H001-13H250)	14	1929	92BR	14	1929	259BE52 / 259BE53	25	1979
H (SINGLE)	3.5	1913-14	104B62 / 104B63	9.9	1974	259BF62 / 259BF63	25	1979
H (#30,000 and UP)	4	1926	105B62 / 105B63	9.9	1975	300	7	1929
J	4	1927-29	106B62 / 106B63	9.9	1976	301	7	1929
K	4	1927-29	107B62 / 107B63	9.9	1977	302	11	1929
L	4	1923-26	108B62 / 108B63	9.9	1978	303	11	1929
LA / LAT	4	1923-26	109B62 / 109B63	9.9	1979	305	25	1929
N	2.5	1923-28	143	20	1929-32	306	25	1929
NF	2.5	1929	145	14	1929-33	307	18	1928
NS	2.5	1923-27	154B64 / 154B65	15	1974	308	18	1928
R / RS	4	1927	155B64 / 155B65	15	1975	309	3.5	1929
T / TS	8	1927	156	22	1930-34	310	14	1930
U (#U1001-U5200)	16	1928	156B64 / 156B65	15	1976	311	14	1930
U (#1U001-15U000)	20	1929	157	22	1930-34	312	14	1930
40B6	4	1970	157B64 / 157B65	15	1977	313	14	1930
41B06	4	1971	158B64 / 158B65	15	1978	314	30	1930
41B36	4	1971	159B64 / 159B65	15	1979	315	30	1930
42B36 / 42B37	4	1972	160	11	1930	335	35	1930
43B36 / 43B37	4	1973	161	7	1930	336	40	1930
44B36 / 44B37	4	1974	162	2.75	1930	340	9	1929
44B66 / 44B67	4	1974	163	11	1930	344	40	1930
45B36 / 45B37	4	1975	167	22	1930	348	7	1930
45B66 / 45B67	4	1975	168	22	1930	355	7	1928
46B36 / 46B37	4	1976	176	20	1930	356B62 / 356B63	35	1976
46B66 / 46B67	4	1976	177 (RACING)		1930	357B62 / 357B63	35	1977
47B36 / 47B37	4	1977	178 (RACING)		1930	358	4	1931
47B66 / 47B67	4	1977	179 (RACING)		1930	358B62 / 358B63	35	1978
48B36 / 48B37	4	1978	180B2 / 180B3	18	1970	359	4	1931
48B66 / 48B67	4	1978	183	2.5	1931	359B62 / 359B63	35	1979
49B6	4	1969	203B02 / 203B03	20	1973	360	3.5	1931
49B36 / 49B37	4	1979	204B62 / 204B63	20	1974	361	13.7	1933

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
362	13.7	1933	432	2.2	1933	490	2.2	1935
363	13.7	1933	433	2.2	1933	491	4	1935
364	13.7	1933	434	2.2	1933	492	8.5	1937-38
365	13.7	1934	436	2.2	1933	492	8.5	1935-36
366	13.7	1934	437	2.2	1933	494	4	1936
367	1.8	1940-41	438	2.2	1933	495	4	1936-37
368	3	1940-41	440	3	1933	496	8.5	1936-37
369	3	1940-41	441	4	1933	497	8.5	1936
371	5	1940-41	442	5.1	1933	498	2.5	1937
373	5	1940-41	443	5.1	1933	499	4.2	1937-38
375	15.2	1940-42	444	5.1	1933	499	5	1939
377	1	1941	445	5.1	1933	500	11	1934-35
378	3.3	1941-42	446	5.1	1933	500	15	1931-33
379	3.3	1941-47	447	1.8	1938	600	21	1931
381	1	1946-47	448	5.1	1933	601	25	1931-33
400	4	1931-35	449	2.8	1938	602	25	1931-33
401	4	1931	449	3	1939	603	25	1931-33
402	4	1931	450	8.5	1933	604	25	1931-33
403	2.75	1931	451	8.5	1933	605	25	1931-33
404	2.75	1931	452	8.5	1933	606	25	1931-33
404B64 / 404B65	40	1974	453	8.5	1933	607	25	1931-33
405	4	1931	454 (RACING)		1933	608	25	1931-33
405B64 / 405B65	40	1975	456	8.5	1933	609 (RACING)		1931
406	4	1931	457	8.5	1933	610 (RACING)		1931
406B64 / 406B65	40	1976	458	8.5	1933	615	21	1931-32
407	4	1932	459	8.5	1933	616	21	1931-32
408	4	1932	460	5.1	1933	617	21	1931-32
409	4	1932	461	5.1	1933	618	25	1932
410	4	1932	462	5.1	1933	619	25	1932
411	4	1932	463	1.8	1940	620	25	1932
412	4	1932	464	2.2	1933	621	25	1932
413	4	1932-33	465	1.8	1939	624	25	1932
414	4	1932-33	466	5	1939	625	25	1932
415	3	1932-34	467	8.5	1939	626	25	1932
416	4	1932-35	468	5.1	1933	627	25	1932
417	8	1932-34	469	1	1939	630 (RACING)		1932
418	11	1932	469	1	1940	631 (RACING)		1932
419	11	1932	470	5.1	1933	634	21.1	1933
420	5.8	1932-33	471	8.5	1939-41	635	21.1	1933
421	5.8	1932-33	472	2.2	1933	636	21.1	1933
422	11	1932	474	2.2	1933	637	21.1	1933
423	11	1932	475	5	1940	638	21.1	1933
424	5.8	1932-33	476	4	1933	639	21.1	1933
425	5.8	1932-33	477	1.8	1939	640	21.1	1933
426	4	1932	478	4	1933	641	21.1	1933
427	4	1932	479	4	1933	642 (RACING)		1933
428	4	1932	481 (ELECTRIC)		1933	643 (RACING)		1933
429	4	1932	483	4	1933	700	35	1931
430	5.8	1932	484	4	1933	701	35	1931
431	5.8	1932	489	2.2	1934	702	35	1931

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
703	35	1931	822	40	1932	3020	3	1956
704	35	1931	823	40	1932	3022	3	1957
705	35	1931	824	40	1932	3023	3	1957
706	35	1931	825	40	1932	3024	3	1957
707	35	1931	826 (RACING)		1932	3026	3	1958
708	35	1931	827 (RACING)		1932	3027	3	1958
709	35	1931	828 (RACING)		1933	3028	3	1958
710	35	1931	829 (RACING)		1933	3030	3	1959
711	35	1931	900	18	1931	3031	3	1959
715	36	1932	901	18	1931	3032	3	1959
716	36	1932	902	18	1931	3034	3	1960
717	36	1932	903	18	1931	3035	3	1960
718	36	1932	905	12	1931-33	3036	3	1960
719	36	1932	906	12	1931-33	3038	3	1961
720	36	1932	907	12	1931-33	3039	3	1961
721	36	1932	912	18	1932	3040	3	1961
722	36	1932	913	18	1932	3042	3	1962
723	36	1932	914	18	1932	3043	3	1962
724	36	1932	915	18	1932	3044	3	1962
725	36	1932	920	18	1933	3302	3	1963
726	36	1932	921	18	1933	3303	3	1963
728	31.2	1933	922	18	1933	3312	3	1963
729	31.2	1933	923	18	1933	3402	3	1964
730	31.2	1933	924	18	1933	3403	3	1964
731	31.2	1933	925	18	1933	3412	3	1964
732	31.2	1933	926	18	1933	3432	3	1964
733	31.2	1933	927	18	1933	3433	3	1964
734	31.2	1933	1002	1.5	1970	3502	3	1965
735	31.2	1933	1802	1.5	1968	3503	3	1965
800	40	1931	1902	1.5	1969	3512	3	1965
801	40	1931	2001	25	1951-52	3532	3	1965
802	40	1931	2002	25	1951-52	3533	3	1965
803	40	1931	2003	25	1952	3602	3	1966
804 (RACING)		1931	2004	25	1952	3603	3	1966
806	40	1931	2102	2	1971	3606	3	1966
807	40	1931	2202	2	1972	3612	3	1966-67
808	40	1931	2302	2	1973	3632	3	1966
809	40	1931	2402	2	1974	3633	3	1966
810	40	1931	2502	2	1975	3636	3	1966
811	40	1931	2602	2	1976	3702	3	1967
812	40	1931	2702	2	1977	3703	3	1967
813	40	1931	2802	2	1978	3706	3	1967
814	40	1932	2902	2	1979	3707	3	1967
815	40	1932	3012	3	1952-54	3712	3	1967
816	40	1932	3013	3	1952-54	3716	3	1967
817	40	1932	3014	3	1955	3732	3	1967
818	40	1932	3015	3	1955	3733	3	1967
819	40	1932	3016	3	1955	3736	3	1967
820	40	1932	3018	3	1956	3737	3	1967
821	40	1932	3019	3	1956	3802	3	1968

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
3803	3	1968	4041	8.5	1934	4092	4	1935
3806	3	1968	4042	9.2	1934-35	4093	4	1935
3807	3	1968	4043	9.2	1934-35	4094	4	1935
3832	3	1968	4044	9.2	1934-35	4095	4	1935
3833	3	1968	4045	9.2	1934-35	4096	4	1935
3836	3	1968	4046	9.2	1934-35	4097	4.6	1935
3837	3	1968	4047	9.2	1934-35	4098	4.6	1935
4000	2.2	1934	4048	9.2	1934-35	4099	4.6	1935
4001	2.2	1934	4049	9.2	1934-35	4101	4.6	1935
4002	2.2	1934	4050	5.5	1934	4102	5	1935
4003	2.2	1934	4051	5.5	1934	4103	5	1935
4004	2.2	1934	4052	5.5	1934	4104	5	1935
4005	2.2	1934	4053	5.5	1934	4105	5	1935
4006	2.2	1934	4054	5.5	1934	4106 / 4107	4	1971
4006 / 4007	4	1970	4055	5.5	1934	4106	5	1935
4007	2.2	1934	4056	5.5	1934	4107	5	1935
4008	2.2	1934	4057	5.5	1934	4108	5	1935
4009	2.2	1934	4058	2.2	1934	4109	5	1935
4010	2.2	1934	4059	2.2	1934	4111	9.2	1935
4011	2.2	1934	4060	2.2	1934	4112	9.2	1935
4012	2.2	1934	4061	2.2	1934	4113	9.2	1935
4013	2.2	1934	4062	2.2	1934	4114	9.2	1935
4014	2.2	1934	4063	2.2	1934	4115	9.2	1935
4015	2.2	1934	4064	2.2	1934	4116	9.2	1935
4016	4	1934	4065	2.2	1934	4117	9.2	1935
4017	4	1934	4066	4	1934	4118	9.2	1935
4018	4	1934	4067	4	1934	4119 (RACING)		1935
4019	4	1934	4068	4	1934	4121	4	1935
4020	5.1	1934	4069	4	1934	4122	4	1935
4021	5.1	1934	4070	5.5	1934	4123	4	1935
4022	5.1	1934	4071	5.5	1934	4124	4	1935
4023	5.1	1934	4072	5.5	1934	4125	4	1935
4024	5.1	1934	4073	5.5	1934	4126	4	1935
4025	5.1	1934	4074	5.5	1934	4127	4.6	1935
4026	5.1	1934	4075	5.5	1934	4128	4.6	1935
4027	5.1	1934	4076	9.2	1934	4129	5	1935
4028 (RACING)		1934	4077	9.2	1934	4131	5	1935
4029 (ELECTRIC)		1934-36	4078	2.2	1934	4132	5	1935
4030	5.5	1934	4079	2.2	1934	4133	5	1935
4031	5.5	1934	4080	2.2	1934	4134	9.2	1935
4032	5.5	1934	4081	2.2	1934	4135	9.2	1935
4033	5.5	1934	4082	4	1934	4136 / 4137	4	1971
4034	8.5	1934	4083	4	1934	4136	9.2	1935
4035	8.5	1934	4084	4	1934	4137	9.2	1935
4036 / 4037	4	1970	4085	4	1934	4138	4	1935
4036	8.5	1934	4086	5.5	1934	4139	1.5	1935
4037	8.5	1934	4087	5.5	1934	4142	4.6	1935
4038	8.5	1934	4088	9.2	1934	4143	4	1935
4039	8.5	1934	4089	9.2	1934	4144	4	1935
4040	8.5	1934	4091	1.5	1935	4144	4.3	1936

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
4145	1.4	1936-37	4198	4.7	1936	4253	1.1	1938
4146	1.5	1936	4199	9.2	1936	4254	2	1938
4147	1.5	1936	4200	9.2	1936	4255	2	1938
4148	4.4	1936	4201	0.9	1937	4256	1.8	1938
4149	4.4	1936	4203	0.9	1937	4257	1.8	1938
4151	4.3	1936	4205	1.4	1937	4258	3	1938
4152	4.4	1936	4206	1.4	1937	4259	3	1938
4153	4.7	1936	4206	4	1972	4261	2.8	1938
4154	4.7	1936	4207	1.6	1937	4262	2.8	1938
4155	4.7	1936	4208	1.6	1937	4263	0.5	1939-41
4156	2.5	1936	4209	2.5	1937	4264	0.5	1939-41
4157	2.5	1936	4211	2.5	1937	4265	1.1	1939-41
4158	2.5	1936	4212	2.5	1937	4266	1.1	1938-41
4159	2.5	1936	4213	2.5	1937	4267	4.7	1938
4161	4.3	1936	4214	4.3	1937	4268	4.7	1938
4162	4.3	1936	4215	4.3	1937	4269	4.7	1938
4163	4.3	1936	4216	4.3	1937	4271	9.2	1938
4164	4.3	1936	4217	4.3	1937	4272	9.2	1938
4165	5	1936	4218	4.3	1937	4273	9.2	1938
4166	5	1936	4219	9.2	1937	4274	9.2	1938
4167	5	1936	4221	4.7	1937	4275	9.2	1938
4168	5	1936	4222	4.7	1937	4276	9.2	1938
4169	5	1936	4223	4.7	1937	4277	9.2	1938
4171	5	1936	4224	4.7	1937	4278	9.2	1938
4172	5	1936	4225	4.7	1937	4279	9.2	1938
4173	5	1936	4226	4.7	1937	4281	9.2	1938
4174	5	1936	4227	4.4	1937	4282	9.2	1938
4175	5	1936	4228	4.4	1937	4283	9.2	1938
4176	5	1936	4229	4.3	1937	4284 (RACING)		1938
4177	5	1936	4231	9.2	1937	4285	2	1938
4178	9.2	1936	4232	9.2	1937	4286	2	1938
4179	9.2	1936	4233	9.2	1937	4287	3	1938
4180	9.2	1936	4234	9.2	1937	4288	3	1938
4181	9.2	1936	4235	9.2	1937	4289	4.7	1938
4182	9.2	1936	4236	4	1972	4291	4.7	1938
4183	9.2	1936	4236	9.2	1937	4292	4.7	1938
4184 (RACING)		1936	4237	9.2	1937	4293	4.7	1938
4185	9.2	1936	4238	9.2	1937	4294	4.7	1938
4186	9.2	1936	4239	9.2	1937	4295	4.7	1938
4187	9.2	1936	4241	9.2	1937	4296	2	1939
4188	9.2	1936	4242	9.2	1937	4297	2	1939
4189	9.2	1936	4243	9.2	1937	4298	2	1939
4190	9.2	1936	4244 (RACING)		1937	4299	2	1939
4191	9.2	1936	4245	9.2	1937	4301	1.8	1939
4192	4.4	1936-38	4246	9.2	1937	4302	1.8	1939
4193	4.3	1936	4247	9.2	1937	4303	3.3	1939
4194	4.4	1936	4248	9.2	1937	4304	3.3	1939
4195	1.4	1936	4249	9.2	1937	4305	3.3	1939
4196	4.7	1936	4251	4.4	1937	4306	3.3	1939
4197	4.7	1936	4252	1.1	1938	4306	4	1973

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
4307	3	1939	4366	2	1941-42	4429	5.4	1949
4308	3	1939	4367	2	1941-42	4431	5.4	1949
4309	5.4	1939	4368	3.3	1941-46	4432	5	1949
4311	5.4	1939	4369	3.3	1941-46	4434	7.5	1950
4312	5.4	1939	4371	3.3	1941-46	4435	7.5	1950
4313	5	1939-41	4372	3.3	1941-46	4436	4	1974
4314	5	1939-41	4373	9.7	1942	4438	14	1950
4315	9.7	1939	4374	9.7	1942	4439	14	1950
4316	9.7	1939	4375	9.7	1943	4441	14	1951
4317	9.7	1939	4376	9.7	1943	4442	14	1951
4318	9.7	1939	4377	9.7	1943	4443	7.5	1951-52
4319	9.7	1939	4378	5.4	1945-46	4444	7.5	1951-52
4321	9.7	1939	4379	5.4	1945-46	4447	7.5	1952
4322	9.7	1939-42	4381	5.4	1945-46	4448	7.5	1952
4323	9.7	1939-42	4382	5.4	1945-46	4506	4	1975
4324	9.7	1939-42	4383	9.7	1945-49	4536	4	1975
4325	9.7	1939-42	4384	9.7	1945-49	4606	4	1976
4326	9.7	1939-42	4385	9.7	1945-49	4636	4	1976
4327	9.7	1939-42	4386	9.7	1945-49	4706	4	1977
4328 (RACING)		1939-41	4387	9.7	1945-49	4736	4	1977
4329	1.8	1939	4388	9.7	1945-49	4806	4	1978
4331	1.8	1939	4389	9.7	1945-49	4836	4	1978
4332	3	1939	4391	9.7	1945-49	4837	4	1978
4333	3	1939	4392	9.7	1945-49	4902	4	1969
4334	1.1	1939-41	4393	9.7	1945-49	4904	4	1979
4335	8.5	1939-41	4394	9.7	1945-49	4906	4	1969
4336	4	1973	4395	9.7	1945-49	4932	4	1979
4336	8.5	1939-41	4398	9.7	1945	4933	4	1979
4337	5	1939-41	4402	5.4	1946-48	4936	4	1969
4338	5	1939-41	4403	5.4	1946-48	5101	12	1949
4339	5	1939-41	4404	5.4	1946-48	5102	12	1949
4341	5	1940-41	4405	5.4	1946-48	5302	5.5	1963
4346	2	1940	4406	1.1	1946-47	5303	5.5	1963
4347	2	1940	4406	4	1974	5402	5.5	1964
4348	2	1940	4407	1.1	1946-47	5403	5.5	1964
4349	2	1940	4409	2	1946	5502	5	1965
4351	1.8	1940-41	4411	2	1946	5503	5	1965
4352	1.8	1940-41	4412	2	1946	5512	5.5	1956
4353	3.3	1940	4413	2	1946	5513	5.5	1956
4354	3.3	1940	4414	2	1947	5514	5.5	1957
4355	3.3	1940	4415	2	1947	5515	5.5	1957
4356	3.3	1940	4416	2	1947	5516	5.5	1958
4357	3	1940	4417	2	1947	5517	5.5	1958
4358	3	1940	4418	3.3	1947	5518	5.5	1959
4359	5.4	1940-41	4419	3.3	1947	5519	5.5	1959
4361	5.4	1940-41	4421	3.3	1947	5520	5.5	1960
4362	5.4	1940-41	4422	3.3	1947	5521	5.5	1960
4363	5.4	1940-41	4423	3.3	1947-51	5522	5.5	1961
4364	2	1941-42	4424	3.3	1947-51	5523	5.5	1961
4365	2	1941-42	4425	1.5	1948-51	5524	5.5	1962

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
5525	5.5	1962	6203	6	1972	7027	33.4	1938
5602	5	1966	6302	6	1973	7028	33.4	1938
5603	5	1966	6303	6	1973	7029	33.4	1938
5702	5	1967	6402	6	1974	7031	33.4	1939-50
5703	5	1967	6403	6	1974	7032	33.4	1939-50
5802	5	1968	6502	6	1965	7033	33.4	1939-41
5803	5	1968	6503	6	1965	7034	33.4	1939-41
6000	21.1	1934	6504	6	1975	7035	33.4	1942
6001	21.1	1934	6505	6	1975	7512	7.5	1953
6002	6	1970	6602	6	1966	7513	7.5	1953
6002	21.1	1934	6603	6	1966	7514	7.5	1954
6003	6	1970	6604	6	1976	7515	7.5	1954
6003	1.1	1934	6605	6	1976	7516	7.5	1954
6004	21.1	1934	6702	6	1967	7517	7.5	1954
6005	21.1	1934	6703	6	1967	7518	7.5	1955
6006	21.1	1934	6704	6	1977	7519	7.5	1955
6007	21.1	1934	6705	6	1977	7520	7.5	1956
6008 (RACING)		1934	6802	6	1968	7521	7.5	1956
6011	21.1	1935	6803	6	1968	7522	7.5	1957
6012	21.1	1935	6804	6	1978	7523	7.5	1957
6013	21.1	1935	6805	6	1978	7524	7.5	1958
6014	21.1	1935	6902	6	1969	7525	7.5	1958
6015	21.1	1935	6903	6	1969	8000 (RACING)		1934
6016	21.1	1935	6904	6	1979	8001 (RACING)		1934
6017 (RACING)		1935	6905	6	1979	8002 (RACING)		1935
6018	21.1	1936	7000	31.2	1934	8003 (RACING)		1936
6019	21.1	1936	7001	31.2	1934	8004 (RACING)		1937
6021	21.1	1936	7002	31.2	1934	8005 (RACING)		1938
6022	21.1	1936	7003	31.2	1934	8006 (RACING)		1939-41
6023	21.1	1936	7004	31.2	1934	8008	50	1943
6024	21.1	1936	7005	31.2	1934	8014	50	1946
6025 (RACING)		1936	7006	31.2	1934	8015	50	1949
6026	22.5	1937	7007	31.2	1934	9000	16.2	1934
6027	22.5	1937	7008	31.2	1935	9001	16.2	1934
6028	22.5	1937	7009	31.2	1935	9002	16.2	1934
6029	22.5	1937	7011	31.2	1935	9003	16.2	1934
6031	22.5	1937	7012	31.2	1935	9004	16.2	1934
6032	22.5	1937	7013	31.2	1935	9005	16.2	1934
6033 (RACING)		1937	7014	31.2	1935	9006	16.2	1934
6034	22.5	1938	7015	31.2	1936	9007	16.2	1934
6035	22.5	1938	7016	31.2	1936	9008	16.2	1935
6036	22.5	1938	7017	31.2	1936	9009	16.2	1935
6037	22.5	1938	7018	31.2	1936	9011	16.2	1935
6038 (RACING)		1938	7019	31.2	1936	9012	16.2	1935
6039	22.5	1939-50	7021	31.2	1936	9013	16.2	1935
6041	22.5	1939-50	7022	33.4	1937	9014	16.2	1935
6042 (RACING)		1939-40	7023	33.4	1937	9015	16.2	1936
6043 (RACING)		1941	7024	33.4	1937	9016	16.2	1936
6102 / 6103	6	1971	7025	33.4	1937	9017	16.2	1936
6202	6	1972	7026	33.4	1938	9018	16.2	1936

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
9019	16.2	1936	10022	10	1961	15032	18	1960
9021	16.2	1936	10023	10	1961	15033	18	1960
9022	9.5	1970	10024	10	1962	15034	18	1961
9022	16.2	1937	10025	10	1962	15035	18	1961
9023	9.5	1970	10302	10	1963	15036	18	1962
9023	16.2	1937	10303	10	1963	15037	18	1962
9024	16.2	1937	10422	9.5	1964	15404	15	1974
9025	16.2	1937	10424	9.9	1974	15405	15	1974
9026	16.2	1938	10425	9.9	1974	15454	15	1974
9027	16.2	1938	10454	9.9	1974	15455	15	1974
9028	16.2	1938	10455	9.9	1974	15502	15	1965
9029	16.2	1938	10522	9.5	1965	15504	15	1975
9031	16.2	1939	10524	9.9	1975	15505	15	1975
9032	16.2	1939	10525	9.9	1975	15554	15	1975
9033	16.2	1939	10554	9.9	1975	15555	15	1975
9034	16.2	1939	10555	9.9	1975	15602	15	1966
9035	17.6	1940-41	10622	9.5	1966	15604 / 15605	15	1975
9036	17.6	1940-41	10624	9.9	1976	15654	15	1976
9037	17.6	1940-41	10625	9.9	1976	15655	15	1976
9038	17.6	1940-41	10654	9.9	1976	15702 / 15703	15	1967
9039	15	1941	10655	9.9	1976	15704	15	1977
9041	17.6	1941	10722	9.5	1967	15705	15	1977
9122	9.5	1971	10724	9.9	1977	15754	15	1977
9123	9.5	1971	10725	9.9	1977	15755	15	1977
9222	9.5	1972	10754	9.9	1977	15802	15	1968
9223	9.5	1972	10755	9.9	1977	15804	15	1978
9322	9.5	1973	10822	9.5	1968	15805	15	1978
9323	9.5	1973	10824	9.9	1978	15854	15	1978
9422	9.5	1964	10825	9.9	1978	15855	15	1978
9423	9.5	1964	10835	9.9	1978	15904	15	1979
9522	9.5	1965	10854	9.9	1978	15905	15	1979
9523	9.5	1965	10855	9.9	1978	15918	15	1956
9622	9.5	1966	10922	9.5	1969	15919	15	1956
9623	9.5	1966	10924	9.9	1979	15922	18	1957
9722	9.5	1967	10925	9.9	1979	15923	18	1957
9723	9.5	1967	10935	9.9	1979	15926	18	1958
9822	9.5	1968	10954	9.9	1979	15927	18	1958
9823	9.5	1968	10955	9.9	1979	15954	15	1979
9922	9.5	1969	15012	15	1953-54	15955	15	1979
9923	9.5	1969	15013	15	1953-54	18002	18	1970
10012	10	1956	15014	15	1955	18003	18	1970
10013	10	1956	15015	15	1955	18102	18	1971
10014	10	1957	15016	15	1956	18103	18	1971
10015	10	1957	15017	15	1956	18202	18	1972
10016	10	1958	15020	18	1957	18203	18	1972
10017	10	1958	15021	18	1957	18302	18	1963
10018	10	1959	15024	18	1958	18303	18	1963
10019	10	1959	15025	18	1958	18304	18	1973
10020	10	1960	15028	18	1959	18305	18	1973
10021	10	1960	15029	18	1959	18402	18	1964

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
18403	18	1964	25603	25	1976	33653	33	1966
18502	18	1965	25652	25	1976	33702	33	1967
18503	18	1965	25653	25	1976	33703	33	1967
18602	18	1966	25702	25	1977	33752	33	1967
18603	18	1966	25703	25	1977	33753	33	1967
18702	18	1967	25752	25	1977	33802	33	1968
18703	18	1967	25753	25	1977	33803	33	1968
18802	18	1968	25802	25	1978	33852	33	1968
18803	18	1968	25803	25	1978	33853	33	1968
18902	18	1969	25832 / 25833	25	1978	33902	33	1969
18903	18	1969	25852	25	1978	33903	33	1969
20202 / 20203	20	1972	25853	25	1978	33952	33	1969
209CR02 / 209CR03	20	1979	25902	25	1969	33953	33	1969
25002	25	1970	25903	25	1969	35012	35	1959
25003	25	1970	25904	25	1979	35013	35	1959
25012	25	1953-54	25905	25	1979	35018	40	1960
25013	25	1953-54	25916	25	1954	35019	40	1960
25014	25	1954	25917	25	1954	35022	40	1961
25015	25	1954	25920	25	1955	35023	40	1961
25018	25	1955	25921	25	1955	35028	40	1962
25019	25	1955	25924	30	1956	35029	40	1962
25022	30	1956	25925	30	1956	35514	35	1958
25023	30	1956	25930	35	1957	35515	35	1958
25028	35	1957	25931	35	1957	35516	35	1959
25029	35	1957	25932 / 25933	25	1979	35517	35	1959
25034	35	1958	25936	35	1958	35520	40	1960
25035	35	1958	25937	35	1958	35521	40	1960
25102	25	1971	25952	25	1979	35524	40	1961
25103	25	1971	25953	25	1979	35525	40	1961
25202	25	1972	28202	28	1962	35530	40	1962
25203	25	1972	28203	28	1962	35531	40	1962
25252	25	1972	28302	28	1963	35602	35	1976
25253	25	1972	28303	28	1963	35603	35	1976
25302	25	1973	28352	28	1963	35652	35	1976
25303	25	1973	28402	28	1964	35653	35	1976
25352	25	1973	28403	28	1964	35702	35	1977
25353	25	1973	28452	28	1964	35703	35	1977
25402	25	1974	33002	33	1970	35752	35	1977
25403	25	1974	33003	33	1970	35753	35	1977
25452	25	1974	33052	33	1970	35802	35	1978
25453	25	1974	33053	33	1970	35803	35	1978
25502	25	1975	33102F / 33103F	33	1971	35852	35	1978
25503	25	1975	33152F / 33153F	33	1971	35853	35	1978
25526	30	1956	33502	33	1965	35902	35	1979
25527	30	1956	33503	33	1965	35903	35	1979
25532	35	1957	33552	33	1965	35932	40	1962
25533	35	1957	33553	33	1965	35933	40	1962
25552	25	1975	33602	33	1966	35952	35	1979
25553	25	1975	33603	33	1966	35953	35	1979
25602	25	1976	33652	33	1966	40002	40	1970

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
40003	40	1970	40602	40	1966	50502 / 50503	50	1975
40052	40	1970	40603	40	1966	50514	50	1958
40053	40	1970	40604	40	1976	50515	50	1958
40072	40	1970	40605	40	1976	50518	50	1959
40073	40	1970	40652	40	1966	50519	50	1959
40102	40	1971	40653	40	1966	50522	75	1960
40103	40	1971	40654	40	1976	50523	75	1960
40152	40	1971	40655	40	1976	50524	75	1961
40153	40	1971	40662	40	1966	50525	75	1961
40172 / 40173	40	1971	40663	40	1966	50528	75	1962
40202	40	1972	40672	40	1966	50529	75	1962
40203	40	1972	40673	40	1966	50542	50	1975
40252	40	1972	40702	40	1967	50543	50	1975
40253	40	1972	40703	40	1967	50572	50	1975
40302	40	1963	40704M	40	1977	50573	50	1975
40303	40	1963	40705M	40	1977	50702 / 50703	50	1977
40304	40	1973	40752	40	1967	50802	50	1978
40305	40	1973	40753	40	1967	50803	50	1978
40352	40	1963	40772	40	1967	50816	50	1959
40353	40	1963	40773	40	1967	50817	50	1959
40354	40	1973	40802	40	1968	50902	50	1979
40355	40	1973	40803	40	1968	50903	50	1979
40362	40	1963	40852	40	1968	50926	75	1961
40363	40	1963	40853	40	1968	50927	75	1961
40372	40	1963	40872	40	1968	50930	75	1962
40373	40	1963	40873	40	1968	50931	75	1962
40402	40	1964	40902	40	1969	55074 / 55075	55	1979
40403	40	1964	40903	40	1969	55602 / 55603	55	1976
40404	40	1974	40952	40	1969	55642	55	1976
40405	40	1974	40953	40	1969	55643	55	1976
40452	40	1964	40972	40	1969	55672	55	1976
40453	40	1964	40973	40	1969	55673	55	1976
40454	40	1974	50012	50	1958	55742 / 55743	55	1977
40455	40	1974	50013	50	1958	55772	55	1977
40462	40	1964	50016	50	1959	55773	55	1977
40463	40	1964	50017	50	1959	55779	55	1977
40472	40	1964	50172	50	1971	55872	55	1968
40473	40	1964	50173	50	1971	55873	55	1968
40502	40	1965	50202	50	1972	55874	55	1978
40503	40	1965	50203	50	1972	55875	55	1978
40504	40	1975	50272	50	1972	55879	55	1978
40505	40	1975	50273	50	1972	55902 / 55903	55	1979
40552	40	1965	50302	50	1973	55972	55	1969
40553	40	1965	50303	50	1973	55973	55	1969
40554	40	1975	50372	50	1973	55974	55	1979
40555	40	1975	50373	50	1973	55975	55	1979
40562	40	1965	50442	50	1974	55979	55	1979
40563	40	1965	50443	50	1974	60062	60	1970
40572	40	1965	50472	50	1974	60063	60	1970
40573	40	1965	50473	50	1974	60072	60	1970

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year	Model Number	HP	Year
60073	60	1970	75433	75	1964	75433	75	1964
60162	60	1971	75452	75	1964	75452	75	1964
60163	60	1971	75453	75	1964	75453	75	1964
60172	60	1971	75482	75	1964	75482	75	1964
60173	60	1971	75483	75	1964	75483	75	1964
60432	60	1964	75492	75	1964	75492	75	1964
60433	60	1964	75493	75	1964	75493	75	1964
60452	60	1964	75532	75	1965	75532	75	1965
60453	60	1964	75533	75	1965	75533	75	1965
60502	60	1965	75542	75	1975	75542	75	1975
60532	60	1965	75543	75	1975	75543	75	1975
60533	60	1965	75552	75	1965	75552	75	1965
60552	60	1965	75553	75	1965	75553	75	1965
60553	60	1965	75582	75	1965	75582	75	1965
60602	60	1966	75583	75	1965	75583	75	1965
60632	60	1966	75592	75	1965	75592	75	1965
60633	60	1966	75593	75	1965	75593	75	1965
60652	60	1966	75642	75	1976	75642	75	1976
60653	60	1966	75643	75	1976	75643	75	1976
60702	60	1967	75742	75	1977	75742	75	1977
60732	60	1967	75743	75	1977	75743	75	1977
60733	60	1967	75749	75	1977	75749	75	1977
60752	60	1967	75842	75	1978	75842	75	1978
60753	60	1967	75843	75	1978	75843	75	1978
60802	60	1968	75849	75	1978	75849	75	1978
65272	65	1972	75942	75	1979	75942	75	1979
65273	65	1972	75943	75	1979	75943	75	1979
65372	65	1973	75949	75	1979	75949	75	1979
65373	65	1973	759B42	75	1979	759B42	75	1979
65832	65	1968	80652	80	1966	80652	80	1966
65833	65	1968	80653	80	1966	80653	80	1966
65852	65	1968	80682	80	1966	80682	80	1966
65853	65	1968	80683	80	1966	80683	80	1966
70442	70	1974	80692	80	1966	80692	80	1966
70443	70	1974	80693	80	1966	80693	80	1966
70472	70	1974	80752	80	1967	80752	80	1967
70473	70	1974	80753	80	1967	80753	80	1967
70572	70	1975	80792	80	1967	80792	80	1967
70573	70	1975	80793	80	1967	80793	80	1967
70672 / 70673	70	1976	85093	85	1970	85093	85	1970
70773 / 70779	70	1977	85193	85	1971	85193	85	1971
70873 / 70879	70	1978	85293	85	1972	85293	85	1972
70973 / 70979	70	1979	85393	85	1973	85393	85	1973
75352	75	1963	85493	85	1974	85493	85	1974
75353	75	1963	85593	85	1975	85593	85	1975
75382	75	1963	85693	85	1976	85693	85	1976
75383	75	1963	85699	85	1976	85699	85	1976
75392	75	1963	85790	85	1977	85790	85	1977
75393	75	1963	85793	85	1977	85793	85	1977
75432	75	1964	85799	85	1977	85799	85	1977

EVINRUDE RECREATIONAL OUTBOARDS 1913-1979

Model Number	HP	Year	Model Number	HP	Year
85852	85	1968	125283	125	1972
85853	85	1968	135342	135	1973
85890	85	1978	135383	135	1973
85892	85	1968	135443	135	1974
85893	85	1968	135483	135	1974
85895	85	1978	135489	135	1974
85899	85	1978	135543	135	1975
85990	85	1979	135583	135	1975
85993	85	1969	135589	135	1975
85995	85	1979	135643	135	1976
85999	85	1979	135683	135	1976
90482	90	1964	140740	140	1977
90483	90	1964	140743	140	1977
90492	90	1964	140783	140	1977
90493	90	1964	140840	140	1978
90582	90	1965	140843	140	1978
90583	90	1965	140883	140	1978
90592	90	1965	140940	140	1979
90593	90	1965	140943	140	1979
100193	100	1971	140983	140	1979
100293	100	1972	150840	150	1978
100683	100	1966	150849	150	1978
100693	100	1966	150940	150	1979
100782	100	1967	150949	150	1979
100783	100	1967	175740	175	1977
100882	100	1968	175749	175	1977
100883	100	1968	175840	175	1978
100990	100	1979	175849	175	1978
100993	100	1979	175940	175	1979
100999	100	1979	175949	175	1979
115083	115	1970	200640	200	1976
115393	115	1973	200649	200	1976
115493	115	1974	200740	200	1977
115499	115	1974	200749	200	1977
115593	115	1975	200840	200	1978
115599	115	1975	200849	200	1978
115693	115	1976	200940	200	1979
115699	115	1976	200949	200	1979
115742	115	1967	235840	235	1978
115790	115	1977	235849	235	1978
115793	115	1977	235940	235	1979
115799	115	1977	235949	235	1979
115890	115	1978			
115893	115	1978			
115899	115	1978			
115983	115	1969			
115990	115	1979			
115993	115	1979			
115999	115	1979			
125183	125	1971			